




Raven X HSDPA

User Guide



Version 2.33 - February 2007



Information in this document is subject to change without notice.

©Copyright AirLink Communications, Inc., 1993-2007. All rights reserved.

WARNING

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

Important Notice

Because of the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the AirLink Communications modem are used in a normal manner with a well-constructed network, the AirLink modem should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. AirLink Communications, Inc., accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the AirLink Communications modem, or for failure of the AirLink Communications modem to transmit or receive such data.

Safety and Hazards

Do not operate the AirLink Communications modem in areas where blasting is in progress, where explosive atmospheres may be present, near medical equipment, near life support equipment, or any equipment which may be susceptible to any form of radio interference. In such areas, the AirLink Communications modem **MUST BE POWERED OFF**. The AirLink Communications modem can transmit signals that could interfere with this equipment. Do not operate the AirLink Communications modem in any aircraft, whether the aircraft is on the ground or in flight. In aircraft, the AirLink Communications modem **MUST BE POWERED OFF**. When operating, the AirLink Communications modem can transmit signals that could interfere with various on board systems. The driver or operator of any vehicle should not operate the AirLink Communications modem while in control of a vehicle. Doing so will detract from the driver or operator's control and operation of that vehicle. In some states and provinces, operating such communications devices while in control of a vehicle is an offence.

Limitation of Liability

The information in this manual is subject to change without notice and does not represent a commitment on the part of AirLink Communications, Inc. AIRLINK COMMUNICATIONS, INC. SPECIFICALLY DISCLAIMS LIABILITY FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS OR REVENUE OR ANTICIPATED PROFITS OR REVENUE ARISING OUT OF THE USE OR INABILITY TO USE ANY AIRLINK COMMUNICATIONS, INC. PRODUCT, EVEN IF AIRLINK COMMUNICATIONS, INC. HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE OR FOR CLAIMS BY ANY THIRD PARTY.

Warranty Summary

For the full and complete text, refer to the warranty appendix in the modem user guide or to the AirLink website (<http://www.airlink.com>) for the full text of the warranty.

Software: Software is warrantied for 90 days to work in substantial conformance to applicable software specifications. AirLink's sole obligation is to, at their option, refund the license fee or replace the software with other software.

Hardware: All equipment is warrantied for one year after delivery to conform with AirLink's specifications and be free from manufacturing defect. Optional warranty extensions can be purchased for two and four years which would increase the warranty period to three and five years respectively. If under normal use, the hardware proves to have any such defect and the Customer notifies AirLink of such defect within the warranty period, AirLink, at its option, will either repair or replace the same without charge but only upon written authorization and in accordance with instructions of AirLink using a Return Material Authorization ("RMA") process (details of the process are in the full warranty statement).

THIS WARRANTY DOES NOT COVER PRODUCTS THAT DO NOT CONFORM TO SPECIFICATIONS BECAUSE OF ACCIDENT, ALTERATIONS, FAILURE TO FOLLOW INSTRUCTIONS, USE OUTSIDE THE SCOPE OF ANY OTHER PROVIDED DOCUMENTATION (E.G., USER GUIDE, INSTALLATION GUIDE, QUICK START GUIDE), MISUSE, ABUSE, NEGLIGENCE, FIRE, FLOOD OR ACTS OF GOD.

Contents

Introduction to Raven X HSDPA	1
HSDPA Overview	1
Establishing an Internet Connection	2
<i>Dynamic vs. Static IP Addresses</i>	2
<i>Using Your Raven X to Connect to the Internet</i>	3
Common Uses for the Raven X	3
Activation of the Raven X	5
Installing the SIM	5
<i>Remove the SIM slot cover.</i>	5
<i>Eject the SIM tray.</i>	5
<i>Insert the SIM into the tray.</i>	6
<i>Insert the tray with the SIM back into the Raven X.</i>	6
<i>Replace the SIM slot cover.</i>	7
Setting the APN with Wireless Ace	7
Utilities for the Raven X	10
AceView	10
Wireless Ace	11
AceNet	12
Modem Doctor	13
IP Manager and DNS	14
Fully Qualified Domain Name	15
Dynamic Names	16
Configuring the Raven X for Dynamic IP	16
<i>Eairlink.com</i>	17
DNS: Using Names Instead of IP addresses	17
<i>Configuring DNS</i>	18
Data Communication and Host Modes	20
AT Mode	21
PassThru Mode	22
Telnet	23
Public and Private Mode	24
Internal DHCP Server	25
<i>DHCP and Routing</i>	25
<i>DHCP in the Raven X using Public Mode</i>	25



<i>PPPoE with DHCP</i>	25
The AirLink Modem as a Gateway	26
Keepalive	26
<i>Configuring Keepalive</i>	26
<i>Data usage using Keepalive</i>	27
Hardware Installation	28
Connecting the Antenna	28
Connecting Power	28
Connecting the Raven X to a computer or other device	29
Raven X Indicator Lights	29
<i>Monitoring Power-In Voltage and Internal Temperature</i>	30
Modem Placement	31
<i>Built in Mounting Tabs for Raven X</i>	31
Specifications for the Raven X HSDPA	32
<i>Physical Characteristics:</i>	32
<i>Environmental:</i>	32
<i>Power Management:</i>	33
<i>Power consumption</i>	33
<i>Serial Port Pinouts</i>	33
AT Commands	34
Using Wireless Ace	34
Using Telnet Terminal Emulation	36
Direct Serial Connection	37
Using AT Commands with a Terminal Application	38
AT Command Listing	40
<i>Information and Status</i>	41
<i>Serial</i>	48
<i>TCP</i>	52
<i>UDP</i>	54
<i>DNS</i>	57
<i>Dynamic IP</i>	58
<i>PPP/Ethernet</i>	60
<i>PassThru</i>	62
<i>SMTP (including SMS)</i>	64
<i>Other</i>	66
<i>Friends</i>	69
<i>Logging</i>	70
<i>EDGE/HSDPA</i>	72
PPPoE: Point to Point Protocol over Ethernet	73
PPPoE (PPP over Ethernet) Configuration	73
<i>Configuring your Raven X for PPPoE</i>	73
Configuring a PPPoE Connection in Windows	75
<i>Connecting to the Internet with PPPoE</i>	81
Configuring your router for PPPoE with the Raven X	82



Simple Network Management Protocol (SNMP)	83
SNMP Overview	83
<i>Management Information Base (MIB)</i>	83
<i>SNMP Traps</i>	83
Raven X SNMP Configuration	83
<i>Listening Port</i>	84
<i>Security Level</i>	84
<i>User Name and Password</i>	84
<i>Trap Destination</i>	85
SNMP MIB Definition for AirLink	85
Warranty Terms and Conditions	92
Warranty Terms	92
<i>Standard Software Warranty</i>	92
<i>One Year Standard Equipment Warranty</i>	92
<i>Optional Two Year Extended Equipment Warranty</i>	92
<i>Optional Four Year Extended Equipment Warranty</i>	92
Warranty Conditions	93
<i>Remedy</i>	93
<i>WARRANTY DISCLAIMER</i>	93
<i>LIMITATION OF LIABILITY</i>	93
<i>General Conditions</i>	94
Frequently Asked Questions and Technical Support	95
FAQ Topics	95
<i>Power, Antennas, and Signal Strength</i>	95
<i>The Raven X's IP Addresses and Local Networking</i>	97
<i>Security for the Raven X</i>	100
AirLink Technical Support	102
<i>AirLink Support Web Site</i>	102
<i>AirLink Documentation and Guides</i>	102
<i>Contacting Technical Support</i>	102

Introduction to Raven X HSDPA

The Raven X's rugged form factor is ideal for industrial and commercial applications that require real-time communications. The Raven X provides cellular data communications for a variety of applications, such as primary or backup Internet connectivity, public safety, traffic control, traffic metering, and more.

FIGURE 1. Raven X front and back



HSDPA Overview

HSDPA (High-Speed Downlink Packet Access) is a cellular technology allowing for higher data transfer speeds, up to 14.4 Mbit/s per cell in the downlink and 2 Mbit/s per cell in the uplink. HSDPA uses Adaptive Modulation and Coding (AMC), fast packet scheduling at the Node B (Base Station) and fast retransmissions from Node B (known as HARQ-Hybrid Automatic Repeat Request) to deliver the improved downlink performance vs. UMTS and EDGE.

HSPDA falls back to UMTS, EDGE or GPRS (in order of precedence). This feature allows you to have seamless connectivity no matter where your Raven X is.

UMTS (Universal Mobile Telecommunications System) supports up to 1920 kbit/s data transfer rates, although most users can expect performance up to 384 kbit/s. A UMTS network uses a pair of 5 MHz channels, one in the 1900 MHz range for uplink and one in the 2100 MHz range for downlink.

EDGE (Enhanced Data rates for GSM Evolution) provides end-to-end packet data services with an enhanced connectivity building on GPRS technology and using the established GSM networks. EDGE provides higher transmission rates and better transmission quality for data than GPRS. EDGE can carry data at speeds typically up to 384 kbit/s in packet mode.



General Packet Radio Service (GPRS) is packet-switched with many users sharing the same transmission channel, but only transmitting when they have data to send. This means that the total available bandwidth can be immediately dedicated to those users who are actually sending at any given moment, providing higher utilization where users only send or receive data intermittently. GPRS provides speeds of 30–70 kbps with bursts up to 170 kbps.

Establishing an Internet Connection

The Raven X uses Cingular as an ISP (Internet Service Provider) to connect you to the Internet.

Steps of a connection:

1. When your Raven X is powered on, it automatically searches for cellular service using HSDPA.
2. Your Raven X establishes a PPP (Point to Point Protocol or “dial” up connection) link to Cingular’s network, also called registering on the network, and receives an IP address.
3. When your Raven X has received its IP address from Cingular, then it is ready to allow you to connect to the Internet.

FIGURE 2. Using the Raven X to connect to the Internet



Dynamic vs. Static IP Addresses

As stated above, when your Raven X registers on Cingular’s network, it receives an IP address. There are two types of addresses on networks: dynamic and static.

- Dynamic addresses are assigned on a “need to have” basis. Your Raven X might not always receive the same address each time it connects with Cingular.
- Static addresses are permanently assigned to a particular account and will always be used whenever your Raven X connects to the Internet. The IP address will not be given to anyone else.



Most ISPs (cellular included) use dynamic IP addresses rather than static IP addresses since it allows them to reuse a smaller number of IP addresses for a large number of customers. A dynamic IP address is suitable for many common Internet uses, such as web browsing, looking up data on another computer system, or other client functions (such as data only being sent out or only being received after an initial request).

If you need to contact your Raven X, a device connected to the modem, or a host system using the modem from the Internet, you need to have a known IP (such as one which is static) or domain name (an IP address which is converted by a DNS server into a word based name). If you have a dynamic IP address for your modem, you can use a Dynamic DNS service (such as IP Manager, page 14) to translate your IP address into to a domain name.



Caution: If you want to connect remotely to your Raven X using TCP/IP, the IP address given to your modem by the network cannot be a private or internal IP address (such as a custom APNData Link) unless you are on the same network or inside that network's firewall (such as with frame relay).

Using Your Raven X to Connect to the Internet

In Public Mode, your Raven X will pass the IP address from Cingular's network to your device or computer. In Private Mode, your modem will assign configured, static local network IP addresses for the modem and your device.

The modem will perform a **one-to-one** routing for all internet traffic to and from the computer or other end device.




If you need to have more than one device connected to the Internet through the modem, you will need to have a router connected to the modem. The modem would provide the one-to-one connection to the router with the router configured to provide a broader NAT service to the other devices connected to it.

You can connect directly through your Raven X to the Internet using the Ethernet port or use PPPoE for a password protected connection. For a direct connection, the Raven X features DHCP (enabled by default) so you don't need to worry about setting up an IP address on your computer. DHCP works with both Private and Public Modes.

To use your Raven X's serial port to connect to the Internet from your computer, you need to connect the computer directly to the Raven X's serial port with a straight-through serial cable and use Dial-Up Networking (DUN).

Common Uses for the Raven X

The Raven X's rugged construction and cellular connection make it ideal for use in remote and/or industrial locations.

**FIGURE 3. Backup connection to the Internet****FIGURE 4. Financial Point of Sale and Kiosk****FIGURE 5. Automation and Telemetry**

Activation of the Raven X

The SIM (Subscriber Identity Module) card in the Raven X is a smartcard securely storing the key identifying a mobile subscriber. Generally, you will only need to install the SIM once in the life of the modem and it may be pre-installed by AirLink.

Installing the SIM

The Raven X is equipped with an easy insertion SIM slot.

1. Remove the SIM slot cover.

Simply remove slot cover on the front of the Raven X to reveal the SIM slot.

FIGURE 1. Slot cover



2. Eject the SIM tray.

Using the tip of a PDA stylus, an unbent paperclip, or other slim *blunt* item press the yellow button of the SIM tray and slide the tray out of the slot.

**FIGURE 2. SIM tray button**

3. Insert the SIM into the tray.

Carefully remove the SIM card from the card you got from Cingular.

FIGURE 3. Sample of a Cingular Card with SIM

Place the SIM into the tray and gently press to click it into place.

FIGURE 4. Empty SIM Tray and a Tray with a Sample SIM

The card and SIM may be a different color than these examples.

4. Insert the tray with the SIM back into the Raven X.

Slide the tray back into the modem and gently press to click it into place.

**FIGURE 5. Inserting the SIM tray**

5. Replace the SIM slot cover.

Replace the cover to prevent dust or other unwanted particles from entering the Raven X. Once the cover is replaced, the installation is complete.



Setting the APN with Wireless Ace

The APN (Access Point Name) is the way your modem knows how it will be communicating with the network. The APN allows custom IP addressing and tailoring your company's wireless IP solution to meet the security and IP addressing requirements of your applications.

Most Cingular accounts use the default addressing solution of Private or Public IP addresses supplied by the Internet and Proxy APNs. Only if you have a Static or Custom IP address should you need to configure a custom APNs.

To configure the APN, you need to use Wireless Ace. If you haven't installed Wireless Ace refer to the "software required" section on page 1 of this guide.

1. Power on your Raven X and connect directly to the Ethernet or serial port on your computer.

2. Start **Wireless Ace** and connect to your modem.

Start > All Programs > AirLink Communications > Wireless Ace 3G > Wireless Ace 3G

A. Click on **Connect**.

If your computer is connected to your modem with an Ethernet cable:

B. Select **UDP** or **TCP**.

C. Type in the modem's local IP (default is **192.168.13.31**).


D. Type in the modem's password (default **12345**).

If your computer is connected to your modem with a serial cable:



- B. Select **PPP**.
- C. Select the COM port to which the modem is connected on your computer (commonly **COM1**).
- D. Type in the modem's password (default **12345**).

FIGURE 6. Wireless Ace: Connect



3. Select **EDGE/HSDPA** from the menu on the left side of Wireless Ace (under “Groups”).

FIGURE 7. Wireless Ace: EDGE/HSDPA

GROUPS	MODEM DATA				PRINTABLE VIEW
PassThru SMTP Other Low Power Friends ----- LOGGING ----- EDGE/HSDPA	AT	Name	Value	New Value	
	*NETAPN	Set APN	internet		
	+COPS	Set Carrier [operator] Selection	0		
	+CGQREQ	Set Quality of Service Profile			
	+CGQMIN	Minimum Acceptable Quality of Service Profile			

4. Type in the APN in the new value field of *NETAPN.

FIGURE 8. Wireless Ace: *NETAPN

SMTP Other Low Power -----	AT	Name	Value	New Value
	*NETAPN	Set APN	internet	Internet

For most Cingular accounts the APN for your modem will be **Internet** or **Proxy**. Consult with your account representative on which APN to use.

If you need to configure your modem for a custom APN, after entering the APN, there is additional information you will need to enter.

- A. Select **Misc** from the menu on the left side under the Common group.



FIGURE 9. Wireless Ace: Common - Misc

GROUPS	MODEM DATA			PRINTABLE VIEW
INFO	AT	Name	Value	New Value
STATUS	*DATE	Date and Time	11/17/2006 18:19:33	
COMMON	OPRG	Enable Over-the-Air Programing	1	
Misc	*NETPHONE	Phone Number	9133784777	
Serial	*STATICIP	Force Static IP	0.0.0.0	
TCP	*DPORT	Device Port	12345	
UDP	*NETUID	Network User ID		
DNS	*NETPW	Network Password		
Dynamic IP	*NETALLOWZEROIP	Allow Last Byte of net IP = Zero	1	
PPP/Ethernet				
PassThru				
SMTP				
Other				
Friends				


- B. Enter the **NAI** into the new value field for ***NETUID** and enter your **network password** into the new value field for ***NETPW**.

FIGURE 10. Wireless Ace: Common - Misc

Dynamic IP	*NETUID	Network User ID		[NAI]
PPP/Ethernet	*NETPW	Network Password		[Password]
PassThru				
SMTP				

5. When you have finished entering the APN settings, click the **Write** button on the tool bar of Wireless Ace and wait for the message “Write Successful” to appear in the status bar.

FIGURE 11. Wireless Ace: Write



6. It is recommended that you reset your modem after configuring the APN. Either click the Reset button in Wireless Ace or press the reset button on the modem.

Utilities for the Raven X

AirLink offers a suite of utilities to optimize your Raven X's performance, allowing you to remotely view status and make changes to the configuration as needed.

- AceView
- Wireless Ace
- AceNet
- Modem Doctor

This section of the Raven X User Guide covers basic information about these utilities. For additional information on a specific application and how to use it, please refer to the user guide for the specific utility.

AirLink modem utilities, except AceNet, are free of charge to those who own AirLink modems. You can download the applications and their user guides from the AirLink web site: <http://www.airlink.com/support>. Contact your dealer or AirLink representative for information on AceNet.



Note: AceView, Wireless Ace, and AceNet require the Microsoft .NET Framework v. 1.1 and Microsoft Windows 98, Windows 2000, Windows XP, or later. You can obtain the Microsoft .NET Framework from Microsoft at: <http://www.microsoft.com/>.



AceView

AceView is a low-profile monitoring tool to view the status of your AirLink Raven X and display network status, IP address, RSSI strength, and other basic connection information.

FIGURE 1. AceView





You can connect to your Raven X locally using a DUN connection or Ethernet across a LAN or connected directly. The display is dynamically updated with the current status of the modem. *The GPS features are available only for PinPoint X, PinPoint-E, and PinPoint modems.*

If you use DUN to connect to your Raven X, AceView can monitor and maintain the DUN connection. *The DUN connection features are not available with Windows NT or Windows 98. Refer to the AceView Guide for information on how to connect using serial for Windows NT or Windows 98.*



Wireless Ace

Wireless Ace enables modems equipped with ALEOS to be monitored and configured locally or remotely.

As long as your Raven X is online and publicly accessible, support personnel can access your modem from anywhere at any time to see how it is operating and how it is configured. Parameter changes can be made instantly over-the-air.


Once your modem is configured and installed correctly, a template can be made to program other modems with the same parameter values. This enables quick, accurate deployment of large pools of modems.



Most configuration screen shots in this guide are using Wireless Ace.

Connecting to the modem using Wireless Ace is covered in the “AT Commands” chapter on page 34.

FIGURE 2. Wireless Ace





AceNet

AceNet is a full featured application that you can use to monitor several AirLink modems at the same time, use a template from Wireless Ace to change the configuration in all of them simultaneously, keep the modems up-to-date with the latest firmware by updating them over the air, periodically log the modems' Status parameters, and even graphically chart the logged parameters to see trends or other over time information.

AceNet's remote connections use TCP/IP, UDP, or SMS.

AceNet is a separate product which can be purchased from AirLink. Contact your AirLink representative for more information.

FIGURE 3. AceNet





FIGURE 4. AceNet Charting






Modem Doctor

Modem Doctor is a troubleshooting and diagnostics utility. This utility will allow you to get a log file of the Raven X activity which you can then send to AirLink support, erase the current configuration completely, and temporarily set the Raven X to a known configuration to aid in troubleshooting (SOS mode).

FIGURE 5. Modem Doctor



IP Manager and DNS

If you have a fleet of AirLink modems or even if you only have one, it can be difficult to keep track of the current IP addresses, especially if the addresses aren't static but change every time the modem connects to Cingular. If you need to connect to the modem, or the device behind it, it is so much easier to connect when you have a name (car54.mydomain.com, where are you?).

Reasons to contact the modem and/or the connected device:

- Requesting a location update from a delivery truck.
- Contacting a surveillance camera to survey the area.
- Remote access to a computer.
- An oil derrick that needs to be triggered to begin pumping.
- Sending text to be displayed by a road sign.
- Monitoring the status of a remote modem.

Domain names, though, are often only connected to static IP addresses because of the way most domain name (DNS) servers are set-up. Dynamic DNS servers require notification of IP Address changes so they can update their DNS records and link a dynamic IP address to the correct name.

Since many cellular providers, like wire-based ISPs, do not offer static IP addresses or static address accounts cost a premium vs. dynamic accounts, IP Manager was developed to work with a Dynamic DNS server to receive notification from AirLink modems to translate the modem's dynamic IP address to a fully qualified domain name. Thus, you can contact your Raven X directly from the Internet using a domain name.

- Dynamic IP addresses are granted only when your Raven X is connected and can change each time the modem reconnects to the network.
- Static IP addresses are granted the same address every time your Raven X is connected and are not in use when your Raven X is not connected.

A dynamic IP address is suitable for many Internet activities such as web browsing, looking up data on another computer system, data only being sent out, or data only being received after an initial request. However, if you need to contact your Raven X directly, a device connected to the modem, or a host system using your Raven X, a dynamic IP won't give you a reliable address to contact (since it may have changed since the last time it was assigned).



Fully Qualified Domain Name

A domain name is a name of a server or device on the Internet which is associated with an IP address. Similar to how the street address of your house is one way to contact you and your phone number is another, both the IP address and the domain name can be used to contact a server or device on the Internet. While contacting you at your house address or with your phone number employ different methods, using a domain name instead of the IP address actually uses the same method, just a word based name is commonly easier to remember for most people than a string of numbers.

Understanding the parts of a domain name can help to understand how IP Manager works and what you need to be able to configure the modem. A fully qualified domain name (FQDN) generally has several parts.

- **Top Level Domain (TLD):** The TLD is the ending suffix for a domain name (.com, .net, .org, etc.)
- **Country Code Top Level Domain (ccTLD):** This suffix is often used after the TLD for most countries *except the US* (.ca, .uk, .au, etc.)
- **Domain name:** This is the name registered with ICANN (Internet Corporation for Assigned Names and Numbers) or the registry for a the country of the ccTLD (i.e. if a domain is part of the .ca TLD, it would be registered with the Canadian domain registry). It is necessary to have a name registered before it can be used.
- **Sub-domain or server name:** A domain name can have many sub-domain or server names associated with it. Sub-domains need to be registered with the domain, but do not need to be registered with ICANN or any other registry. It is the responsibility of a domain to keep track of its own subs.

car54.mydomain.com

- **.com** is the TLD
- **mydomain** is the domain (usually noted as mydomain.com since the domain is specific to the TLD)
- **car54** is the subdomain or server name associated with the device, computer, or modem registered with mydomain.com

car54.mydomain.com.ca

This would be the same as above, but with the addition of the country code. In this example, the country code (.ca) is for Canada.



A URL (Universal Resource Locator) is different from a domain name in that it also indicates information on the protocol used by a web browser to contact that address, such as <http://www.airlink.com>. www.airlink.com is a fully qualified domain name, but the <http://>, the protocol identifier, is what makes the whole thing a URL.



Dynamic Names

When an IP address is not expected to change, the DNS server can indicate to all queries that the address can be cached and not looked up for a long period of time. Dynamic DNS servers, conversely, have a short caching period for the domain information to prevent other Internet sites or queries from using the old information. Since the IP address of a modem with a dynamic account can change frequently, if the old information was used (such as with a DNS server which indicates the address can be cached for a long period of time) when the IP address changed, the domain would no longer point to the new and correct IP address of the modem.

If your Raven X is configured for Dynamic IP, when it first connects to the Internet, it sends a IP change notification to IP Manager. IP Manager will acknowledge the change and update the Dynamic DNS server. The new IP address will then be the address for your Raven X's configured name.

Once your Raven X's IP address has been updated in IP Manager, it can be contacted via name. If the IP address is needed, you can use the domain name to determine the IP address.



Note: The fully qualified domain name of your Raven X will be a subdomain of the domain used by the IP Manager server.

Configuring the Raven X for Dynamic IP

To configure the Dynamic IP settings in your Raven X so that it will use IP Manager, you can use Wireless Ace or a terminal application to enter the commands (page 34).

To configure your AirLink modem to be addressed by name, the modem needs to have 4 elements configured. You can configure a second dynamic server as a backup, secondary, or alternate server. In Wireless Ace, select **Dynamic IP**.

FIGURE 1. Wireless Ace: Dynamic IP

GROUPS	MODEM DATA			
----- INFO ----- STATUS ----- COMMON Misc Serial TCP UDP DNS Dynamic IP PPP/Ethernet PassThru SMTP Other Low Power	AT	Name	Value	New Value
	*MODEMNAME	Modem Name		car54-2007
	*DOMAIN	Domain	airlink.com	airlink.com
	*IPMANAGER1	IP Manager Server 1 (IP Adrs)		edns2.airlink.com
	*IPMGRUPDATE1	IPMServer1 Update (Minutes)	0	
	*IPMGRKEY1	IPMServer1 Key	*****	
	*IPMANAGER2	IP Manager Server 2 (IP Adrs)		airlink.com
	*IPMGRUPDATE2	IPMServer2 Update (Minutes)	0	
	*IPMGRKEY2	IPMServer2 Key	*****	

***MODEMNAME:** The name you want for the modem.



***DOMAIN:** The domain name to be used by the modem.

***IPMANAGER1** and ***IPMANAGER2:** The IP address or domain name of the dynamic DNS server which is running IP Manager.



Note: To use the name here instead of the IP, you need to have DNS set up in your Raven X (page 17).

***IPMGRUPDATE1** and ***IPMGRUPDATE2:** How often, in minutes, you want the address sent to IP Manager. If this is set to zero, the modem will only send an update if the IP address changes (example, if your Raven X modem is reset or is assigned a different IP address).

***IPMGRKEY1** and ***IPMGRKEY2:** User defined password key which is used instead of AirLink secret key.

Restrictions for Modem Name

For the Modem Name, you should use something which is unique but also easy to remember. Your company name or the intended function of the modem are recommended. If you have more than one modem and want to name them the same, you can append a number for each. Since it is an Internet domain name, there are some restrictions for the name.

- Must begin with a letter or number
- Can include a hyphen (-)
- Cannot contain spaces
- Must be no longer than 20 characters total

Eairlink.com

As a service, Airlink maintains a IP Manager servers which can be used for any AirLink modem.

- ***DOMAIN:** eairlink.com
- ***IPMANAGER1 :** edns2.eairlink.com
- ***IPMANAGER2 :** eairlink.com



Note: The IP Manager service from AirLink is currently not a guaranteed service though every effort is made to keep it operational 24/7.

When using AirLink's IP Manager servers, since there are many AirLink modems using the service, it is even more imperative to have a unique name for your modem.

DNS: Using Names Instead of IP addresses

The Raven X has the ability to query DNS servers in order to translate domain names into IP addresses. This allows you to use domain names in place of IP addresses for most of the configuration options requiring IP addresses. This is important if your Raven X will need to contact another modem or other device that has a domain name but an unknown or dynamic IP address (such as another remote Raven X using IP Manager).



Configuring DNS

Generally, when your Raven X receives its IP address from Cingular, it will also receive Cingular's DNS servers to use for resolving (or translating) names to IP addresses which it will automatically configure in the modem settings. Unless your Raven X will be used on a network with other modems or devices which have names internal to the local network or frequently changing IP addresses, the DNS servers provided by Cingular should be all you need.

If the Raven X will be communicating with a device that has a domain name but changes its IP address frequently (such as another AirLink modem using IP Manager) or is on a network where devices are accessed by names rather than IP addresses, you will want to put in an alternate DNS (*DNSUSER) where that domain is updated, such as the IP Manager server the remote modem is using or the listing of IP addresses to names is kept.

FIGURE 2. Wireless Ace: DNS

GROUPS	MODEM DATA			
COMMON	AT	Name	Value	New Value
Misc	*DNS1	Modem DNS Server 1	209.183.48.10	
Serial	*DNS2	Modem DNS Server 2	209.183.48.11	
TCP	*DNSUSER	Use Alternate DNS	0.0.0.0	
UDP	*DNSUPDATE	DNS Updates	0	
DNS				
Dynamic IP				
PPP/Ethernet				
PassThru				
SMTP				

***DNS1** and ***DNS2** - The primary and secondary DNS servers set by Cingular when your Raven X gets its IP address.

***DNSUSER** - Set this, if desired, to an additional DNS server to query first before the primary or secondary (just as a hosts file is queried first on a computer). If ***DNSUSER** is set to 0.0.0.0, it will be ignored.

***DNSUPDATE** - This command sets how often you want DNS Updates to be requested. Otherwise the Raven X will only send updates when it is reset, powered up, or the IP address is granted by network changes.



Note: If you will be using your Raven X to communicate with another AirLink modem and both are using IP Manager to translate dynamic IP addresses to domain names, it is recommended that you set ***DNSUSER** to the IP address for IP Manager. IP Manager's updates occur more frequently than Cingular's DNS servers decreasing the time between IP address change and address resolution. Likewise, if your Raven X routinely needs to contact another modem or device with a Dynamic DNS domain and that modem or device frequently changes its IP address, you may need to set ***DNSUPDATE** for frequent updates.

PPP-Peer

The Raven X uses the unqualified domain name of "ppp-peer" when it is in PPP or SLIP address mode to resolve the address of the device or computer connected via PPP or SLIP address. If the Raven X is not in PPP or SLIP address mode, "ppp-peer" will resolve to 0.0.0.0.



Data Communication and Host Modes

The Raven X plays the part of a HOST when a computer or another device is connected to its serial or Ethernet port. The Raven X can also route data to/from the connected device to the cellular network.



Note: The Raven X moves data from one port to the cellular network in a simple **one-to-one** routing. It does not employ a routing table or any complicated routing protocol. If you need to have one-to-many routing, you can connect the Raven X to a router. The router would provide the multiple routing and the Raven X would provide one-to-one for the router to the cellular network and the Internet.

As the host, the Raven X can use different communication modes. Some communication modes are not available for specific port types, explained with the description of the mode type.

AT: The Raven X accepts and responds to standard AT commands.

PassThru: Direct connection to internal hardware (OEM Module) of the Raven X.

Telnet: The Raven X auto-answers TCP connections to allow terminal emulation using either the Ethernet port or remotely via the cellular connection.

PPP: The Raven X uses PPP to communicate with a device or computer connected to the serial port.

SLIP: The Raven X uses SLIP to communicate with a device or computer connected to the serial port.

UDP and UDP PAD: Any data received on the serial port is assembled into UDP packets and sent to the session's associated IP address and Port (described later). Any responses received from the associated IP address and port destined for the modem's Device Port are unwrapped and sent out the serial port.

TCP and TCP PAD: Any data received on the serial port is packaged into TCP messages and sent to the associated connection's IP address and Port (described later). Any data received from the TCP peer is unwrapped and sent out the port.

By default, the Raven X is in AT Mode and allows AT Commands to be entered via terminal connection (through the local port connection) or remotely (through the cellular network). PassThru Mode can only be exited by resetting the Raven X. All other modes are entered, for their specific port, by use of a startup mode command.



The serial port of the Raven X can be configured to enter any of the modes automatically on power up (in most cases, this is also after it has registered on the cellular network). This is done by setting the Startup Mode Default (refer to **MD** in the AT Command listing, page 87) to the desired mode. If this setting is non-zero, the modem will enter the specified mode after 5 seconds. If you want to cancel this behavior, the **ATMD0** command can be used before the 5-second time-out expires.

FIGURE 1. Wireless Ace: MD

GROUPS	MODEM DATA			
-----	AT	Name	Value	New Value
INFO	MD	Startup Mode Default	00	
STATUS	S82	UDP Auto Answer	0	
COMMON	S83	UDP Idle Timeout	0	
Misc	HOR	UDP Auto Answer Response	0	
Serial	*UDPLAST	UDP Connect Last	0	
TCP	AIP	Allow Any IP	0	
UDP	*UALL	Allow All UDP	0	
DNS	*DU	Dial UDP Always	0	
Dynamic IP	*USD	UDP Serial Delay	0	
PPP/Ethernet				
PassThru				
SMTP				
Other				
Low Power				
Friends				
LOGGING				

If the serial port of the Raven X is in any mode other than AT or PassThru, the AT command mode can be re-entered by:

- Deactivating DTR (if &D2 or Ignore DTR, S211, is not set).
- Issuing the +++ escape sequence (if Disable AT Escape, DAE, is not set).
- Resetting or Power cycling the modem.



Note: DTR needs to be asserted (S211=1 or &D0) by the host before PPP Mode, SLIP Mode, UDP PAD Mode, or TCP PAD Mode can be entered.

AT Mode

Using a terminal connection, AT commands are used to configure the modem, command it to do something, or query a setting. For a full listing of the AT commands, refer to page 34. Wireless Ace is a graphical user interface for most AT Commands.

AT commands must always be terminated by <CR> (ASCII character 0x0D), a carriage return (pressing enter on the keyboard). Some may also include a new line or line feed <LF>.

If **E=1** (Echo On), the AT command (including the terminating <carriage return>) will be displayed (output) before any responses.

Two settings affect the format of AT command output: V (Verbose) and Q (Quiet).



If **Q=1** (Quiet On), no result codes are output whatsoever, so there is no response generated by a (non query) command.

If **Q=0** (Quiet Off), result codes are output. The format of this output is then affected by the Verbose setting.

If Quiet mode is off, the result code is affected as follows:

For **V=1** (Verbose mode), the textual result code is surrounded by a carriage return and new line. Any AT query response is also surrounded by a carriage return and new line.

For **V=0** (Terse mode), a numeric result code is output with a single trailing carriage return (no new line is output), while any AT query response is followed by a carriage return and new line (there is no preceding output).

For example, possible output to the AT command "AT" with carriage return (assuming quiet mode is not on) is:

carriage return - if V=0

carriage return and new line OK another carriage return and new line - if V=1



Note: These commands work for the port on which they are executed. For example, if the user types ATE1 and then AT&W using a serial port connection, it will set the serial port to Echo On.

PassThru Mode

In PassThru mode, the Raven X does not behave normally, all port communication is passed directly between the internal hardware and the computer connected directly to the modem. This mode can be used to configure hardware-specific settings (for example, provisioning, troubleshooting, etc.).

Issuing the "**AT\APASSTHRU**" from a terminal emulation enters this mode. The modem responds with **OK**, at which point a direct connection to the internal hardware is established.

With Wireless Ace, you can configure a string of AT commands to be sent to the Raven X when it enters PassThru and other PassThru settings.

FIGURE 2. Wireless Ace: PassThru

GROUPS	MODEM DATA			
DNS	AT	Name	Value	New Value
Dynamic IP				
PPP/Ethernet				
PassThru	*PTINIT	Passthrough Init String		
SMTP				
Other	*PTREFRESH	Passthrough Init Refresh (Minutes)	0	
Low Power				
Friends	*RESETPERIOD	Modem Reset Period (Hours)	0	
LOGGING	*CSX1	Passthrough Echo	0	

You can configure MD to have the Raven X enter PassThru on start up.



FIGURE 3. Wireless Ace: MD

GROUPS	MODEM DATA			
INFO	AT	Name	Value	New Value
STATUS	MD	Startup Mode Default	00	
COMMON	S82	UDP Auto Answer	0	00-Normal (AT command)
Misc	S83	UDP Idle Timeout	0	01-SLIP
Serial				02-PPP
TCP	HOR	UDP Auto Answer Response	0	03-UDP
UDP				04-TCP
				07-PassThru
				08-BinPoint MDT

Some internal hardware requires upwards of 20 seconds before AT commands can be entered, so be patient if there seems to be no response to AT commands.



Caution: PassThru can only be exited by resetting or power-cycling the modem. This mode cannot be entered via a remote Telnet session.

PassThru Mode allows only specific AT commands. Some ALEOS commands will be unavailable when the modem is in PassThru mode. The commands usable also depend heavily on the modem model number (found on the label on the top of the modem).



Caution: ALEOS is disabled in PassThru Mode. You cannot use most ALEOS specific commands while the modem is in PassThru Mode. While in PassThru mode, you also cannot use Wireless Ace to connect with the Raven X.

Telnet

In Wireless Ace you can configure Telnet operation.

FIGURE 4. Wireless Ace: Telnet Configuration

GROUPS	MODEM DATA			
COMMON	AT	Name	Value	New Value
Misc	S0	TCP Auto Answer	0	
Serial	S7	TCP Connect Timeout	30	0-OFF
TCP				1-ON
UDP	TCPT	TCP Idle Timeout	0	2-Telnet Server
DNS				3-Telnet (always Echo)
Dynamic IP				

If you need to change the port for Telnet (for example, you have the default port blocked on your firewall), the option is on the Other tab. The default telnet port is **2332**. You can also change the Telnet timeout, if the connection is idle, default 2 minutes.



FIGURE 5. Wireless Ace: Telnet Configuration

GROUPS	MODEM DATA			
PassThru SMTP <u>Other</u> Low Power Friends	AT	Name	Value	New Value
	*TPORT	AT Telnet Port	2332	2332
	*TELNETTIMEOUT	AT Telnet Port Timeout (Minutes)	2	

Public and Private Mode

By default, the Raven X is in Public Mode and will pass the IP address assigned by the Cingular network to the devices connected to its ports. If you need more control over which gateway address, device address, and netmask that is given out by the DHCP server, you can use the private host mode, *HOSTPRIVMODE, and set the internal network IP addresses. The Raven X will use NAT to forward packets to the end device.



Note: When using Public mode, connect the modem directly to the computer or other end device. Using a hub or switch may prevent the modem from updating the IP address of the end device when an IP address is received from the Cingular network.

In Wireless Ace, the Private mode settings are part of the **PPP/Ethernet** group.

FIGURE 6. Wireless Ace: Private Host Mode

GROUPS	MODEM DATA				PRINTABLE
----- COMMON Misc DNS Dynamic IP <u>PPP/Ethernet</u> PassThru SMTP Other Low Power	AT	Name	Value	New Value	
	*HOSTPRIVMODE	Use Private IP	0	1 - Use Private IP	
	*HOSTPRIVIP	Host Private IP	0.0.0.0	192.168.0.2	
	*HOSTPEERIP	Modem Local IP	192.168.13.31	192.168.0.1	
	*HOSTNETMASK	Host network mask	0.0.0.0	255.255.255.0	

- ***HOSTPRIVMODE** - Set to **1** to enable the explicit IP addresses.
- ***HOSTPRIVIP** - Set to the IP address you want the Raven X to give to your device.
- ***HOSTPEERIP** - Set to the IP address you want for the Raven X.
- ***HOSTNETMASK** - Set to the subnetmask (generally, 255.255.255.0).



Note: If you are using Private Mode (*HOSTPRIVMODE=1), you will need to make sure that *HOSTPRIVIP and *HOSTPEERIP are on the same subnet. If the subnet mask is 255.255.255.0, it is safe to use 192.168.x.y for each as long as the x is the same number (0 in the example screen shot above) and the y is different (1 and 2 in the example) and between 0 and 254. The screenshot shows an example.



Internal DHCP Server

DHCP (Dynamic Host Configuration Protocol) has become a primary component of today's network environments. DHCP allows one server to automatically and dynamically allocate network IP addresses and other network related settings (such as subnet masks, routers, etc.) to each computer or device without the need to set up each specifically or keep track of what addresses have already been used.

DHCP and Routing

DHCP is built on a client-server model. The client broadcasts on the local physical subnet to find available DHCP servers (generally only one active per network). The server, when a request is received, reserves an IP address for the requesting client and then sends an IP lease offer to the client which contains the client's MAC address, followed by the IP address that the server is offering, the subnet mask, the lease duration, other IP configuration options, and the IP address of the DHCP server making the offer. Upon receipt of an offer, the client configures its interface accordingly.

Routing, at its most basic level, is the process of forwarding data on to the correct destination. One component of routing is address determination, directing data to the correct address either as its final destination or so it can be forwarded on. Selecting gateways where the data can be directed is another important component of routing.

The Raven X acts as a one to one gateway forwarding messages to and from one device that is connected to it. The Raven X does not provide routing for any more than that one device.

DHCP in the Raven X using Public Mode

1. When the Raven X registers on the cellular network, it is assigned an IP address from Cingular, let's say A.B.C.D.
2. Acting as a DHCP server, in Public Mode, when the Raven X receives a DHCP request from an Ethernet device, it hands off the assigned address to the device and sets up the default gateway address as A.B.C.1. If the fourth octet is already a 1, it assigns A.B.C.2 as the router address.
3. The Raven X also sends a /24 netmask (255.255.255.0) and sets up a static route which maps 192.168.13.31 (or the address configured with *HOSTPEERIP if it is changed) to A.B.C.1 (or A.B.C.2 if that was what the gateway address was given as).

Private Mode allows more direct control of the gateway address, device address, and netmask that is given out by the modem's DHCP server. The IP Address that would be assigned to the end device is configured in the Private Mode settings (see above). Some applications which rely on specific IP addressing for their operation may have issues working in Private Mode when the modem has a non-static IP address.

PPPoE with DHCP

When PPPoE is used with the Raven X, DHCP is not needed. A tunnel is set up connecting a device (such as your computer or a router) with the modem. The device will then simply use the Raven X's MAC address to send all outgoing packets. To configure your Raven X and your computer to work with PPPoE, refer to the appendix for PPPoE, page 73.



The AirLink Modem as a Gateway

The primary purpose of the Raven X is to forward data from a *single* device connected to one of the ports to the Cingular's network and, ultimately, under most circumstances, to the Internet in a **one to one** gateway configuration.

When the Raven X obtains its IP Address from the cellular provider, it also obtains Cingular's routing information necessary to forward messages to Cingular's routers which can then forward on from there. The Raven X then acts as a router for the device connected to it, forwarding to or from Cingular's network.



Caution: The Raven X forwards messages to and from the cellular network for only ONE device per port. The Raven X is a **one-to-one** gateway and does not have advanced routing features required to do one-to-many routing.

Keepalive

Keepalive is used to test the Raven X's connection by pinging an IP address after a specified period of inactivity. Keepalive is only recommended for users who have a remote terminated modem that infrequently communicates to the network or if you have experienced issues over time where the modem can no longer be reached remotely.

When Keepalive pings the IP address, an acknowledgement indicates there is an active connection to the network. If the Raven X does not receive a response from the IP address, it will make additional attempts according to a backoff algorithm before determining the Internet connection is not functioning properly. If it determines the connection is not functioning, the modem will then attempt to reconnect to Cingular to reestablish IP connectivity.

Configuring Keepalive

You can use Wireless Ace or a terminal connection to configure Keepalive (page 34). In Wireless Ace, select **Other** from the groups menu on the left.

FIGURE 7. Wireless Ace: Keepalive Configuration

GROUPS	MODEM DATA				PRIN
PPP/Ethernet	AT	Name	Value	New Value	
PassThru	*IPPING	Keepalive Ping Time	0	<input type="text"/>	
SMTP					
Other					
Low Power	*IPPINGADDR	Keepalive Ping Address	<input type="text"/>	<input type="text"/>	
Friends					

***IPPING** sets the interval, in minutes, you want Keepalive to test the network connection. To disable Keepalive, set *IPPING to 0 (default setting).



Note: 15 minutes is the minimum time which can be set for Keepalive.

***IPPINGADDR** sets the IP address you want to use for the connection test.



Caution: If ***IPPINGADDR** is left blank or is set to an invalid IP address (example, an IP which is unreachable or one which is not a valid IP address), modem performance will be adversely affected.

Data usage using Keepalive

Keepalive is an optional feature. If you frequently pass data with your modem, you most likely do not need to have Keepalive enabled. When using Keepalive, be aware that a ping moves approximately 66 bytes of data over the network and is billable by the carrier. The following ***IPPING** settings will incur approximate monthly data usage in addition to any other data usage:

15 minutes	400k / month	60 minutes	100k / month
30 minutes	200k / month	120 minutes	50k / month

Hardware Installation


Your AirLink Raven X should be mounted in a position that allows easy access for the cables so they are not bent or constricted. The LEDs on the front panel should be visible for ease of operational verification. You should ensure that there is adequate airflow around the modem but that it is kept free from direct exposure to the elements (sun, rain, etc.)

The integrated mounting with keyhole screw mounts on the Raven X will allow you to secure your modem nearly anywhere, quickly and easily, without the need for a separate bracket.



Modem placement with grounding information and diagrams of the mounting tabs can be found in the Appendix, “Modem Placement” on page 31.

FIGURE 1. Raven X connectors



Connecting the Antenna

Antennas selected should not exceed a maximum gain of 5 dBi under standard installation configuration. In more complex installations (such as those requiring long lengths of cable and/or multiple connections), it's imperative that the installer follow maximum dBi gain guidelines in accordance with the FCC's regulations.

Your AirLink Raven X will work with most Dual-Band PCS cellular antennas with a connector that works in the high and low frequencies of HSDPA. Connect the antenna or RF cable directly to the antenna connector on the back of the Raven X.

Connecting Power



Your Raven X can be used with either DC (available in most automobiles) or 110 AC (standard US wall power) with the appropriate power adapter (available from AirLink).

The power cable positive lead should be connected to the battery or power source positive terminal. The power cable negative lead should be connected to the battery or power source negative terminal.



Note: When using a DC power source (such as a car battery or solar cell), AirLink recommends placing a fuse (1-2 Amp) on the line close to the power source to protect your power source from possible surges due to shorts or other line issues.

Connecting the Raven X to a computer or other device

Your Raven X's Ethernet port can be connected directly to a computer or other Ethernet device with either a cross-over cable or a straight-through cable. The Ethernet port on the Raven X is auto-sensing. The Ethernet port will also auto-detect the speed of the connecting device and communicate at 100baseTX or 10baseT.

Your Raven X's serial port can be connected directly to most computers or other devices using a standard straight through cable. If you have a DCE device, you will need a null modem or null modem cable.

Your Raven X can also be connected to a USB to device connected to a computer or other device which does not have an available port but does have USB.

Raven X Indicator Lights

When your Raven X is connected to power and an antenna, there is a specific pattern to the lights to indicate its operation mode.

FIGURE 2. Raven X indicator lights



Network - Indicates a successful connection to the cellular network with an IP address given and a channel acquired.

Signal - Light shows the strength of the signal and may be nearly solid (strong signal) or flashing (weaker signal). A slow flash indicates a very weak signal.

Activity - Lights will flash as data is transferred to and from the Raven X on the remote network.

Service - Indicates when the connection is HSDPA or UMTS. Unlit indicates EDGE or GPRS.



Power- Indicates the power adapter is connected and there is power getting to the modem. .

The **Reset** button (on the left side) has two functions. If it is quickly depressed and released, the modem will simply power cycle the internal hardware. If, however, the reset is depressed and held for several seconds (count 10 slowly), the ALEOS configuration settings will return to the factory defaults.



Caution: If you reset the modem configuration using the reset button, you may need to reconfigure your APN.

Monitoring Power-In Voltage and Internal Temperature

The current status of the power-in voltage and the internal (board) temperature, in Celsius, can be monitored in Wireless Ace.

FIGURE 3. Wireless Ace: *POWERIN and *BOARDTEMP

GROUPS	MODEM DATA			PRINTAB
STATUS	*POWERIN	Power IN Voltage	13.50	
	*BOARDTEMP	Board Temperature	37	


Modem Placement

When decided on a location to install your Raven X, make sure the modem will be away from direct exposure to the elements (sun, rain, etc.). Excess cables can be bundled and tied with twist-ties or other appropriate binders, but the less the cable is wrapped and bound together, the better the modem will perform.

Built in Mounting Tabs for Raven X

The Raven X is equipped with mounting tabs so there is no need for a separate bracket. #6 screws are recommended, though other solutions may be sufficient as well.

FIGURE 1. Diagram of the Raven X bottom, showing the placement of the mounting holes



Specifications for the Raven X HSDPA

Physical Characteristics:

- Weight: 0.7 lbs
- Size: height 1.4" (36mm), length 2.5" (65mm) x width 4.6" (117mm)
width with mounting tabs 5.75" (146mm)
- Send/Receive RF Antenna Connector: 50 Ohm SMA
- Ethernet Interface: RJ-45 Connector, autosensing 100baseTX/10baseT
- Serial Interface: RS232 DB-9F with 300-230400 bps (see below for diagram)
- Status LEDs

Data Services & RF Features

- Quad Band GPRS/EDGE (850, 900, 1800 and 1900 MHz)
- HSDPA data rates 1.8 Mbps maximum, 500-800 Kbps typical downlink and 384 Kbps maximum, 220-320 typical uplink
- UMTS data rates 384 Kbps maximum, 220-320 typical downlink/uplink
- EDGE data rates 236 Kbps maximum, 70-90 typical downlink and 118 maximum, 50-60 typical uplink
- GPRS data rates 7.6 Kbps maximum, 30-50 Kbps typical downlink /uplink
- Coding Schemes 1-9, Full PBCCH Support
- Network: 1900/850 MHz GPRS
- Transmit frequency: 1850-1910 MHz and 824-849 MHz
- Transmit power range at antenna port: 1.0 W for 1900 MHz and 0.8W for 850 MHz
- Transmitter can reduce output power when near a base station as per GSM specifications
- Receiver frequency: 1930-1990 MHz and 869-894 MHz
- Receiver sensitivity: typical -107 dBm (2.439% bit error rate)
- Multislot Class 8

Environmental:

- Certifications: Class 1 Div 2, parts A, B, C, & D



Power Management:

- Low power consumption
- Dormant connection (idle for 10-20 seconds): 104 mA at 12 VDC
- Input Voltage: 9 VDC to 28 VDC
- Input Current: 20 mA to 350 mA


Power consumption

Modem	Dormant/Idle	Receiving	Transmitting
Raven X	85-95 mAh	260-300 mAh	mAh

Serial Port Pinouts

The cable between the Raven X and a computer or other serial device needs to be wired straight-through (pin 1 goes to pin 1, pin 2 to pin 2, etc.). If your end device connected to the Raven X is a DCE device, you will need a null-modem cable.

FIGURE 1. : Female DB-9 DCE



AT Commands



Note: Some commands can only be configured using a terminal emulation and typed AT commands. Some commands also require PassThru mode.



You can use a fully qualified domain name instead of an IP address for most configuration options calling for an IP address if your is configured to use DNS. DNS settings frequently come directly from Cingular while your is registering on the cellular network and receiving it's IP address.



Using Wireless Ace

With Wireless Ace, you only need to find the command listed and then enter the new value in the space provided. For those commands which have specific parameters, the choices will be in a drop down menu.


FIGURE 1. Wireless Ace: Entering new configuration values

GROUPS	MODEM DATA				PRINTABLE VIEW
----- INFO ----- STATUS ----- COMMON Misc Serial TCP UDP DNS	AT	Name	Value	New Value	
	\$53	Destination Address			
	\$53	Destination Port	0		
	\$53	Default Dial Code	T		
					T-TCP P-UDP N-Telnet

To set or commit the changes in the modem, use the **Write** button at the top of Wireless Ace interface.



FIGURE 2. Wireless Ace: Tool bar



For more information on using Wireless Ace, please refer to the **Wireless Ace User Guide**.



With Wireless Ace, you can create a template from one modem and then use that template to configure other modems in the exact same way. You can use the template in AceNet, too, to configure several modems at the same time with the same parameters.

FIGURE 3. Wireless Ace: Save / Load a Template







FIGURE 4. AceNet: Load a Template



Using Telnet Terminal Emulation


It is possible to communicate with the Raven X across a TCP/IP network. Telnet provides a terminal style connection to the Raven X.

Most installations of Microsoft Windows come with a version of HyperTerminal (used here for specific directions), but you can use any other Telnet application, such as Putty, Terra Term, etc.

Start>All Programs>Accessories>Communications>HyperTerminal

1. Choose a name for your connection, such as **Raven X** or **AirLink**. The name and icon are only for your own reference so you can find the connection at a later date (if you want to have a connection saved for both local and remote, it is recommended the connection name reflect the connection type (example, Raven X Remote).

FIGURE 5. HyperTerminal: Connection Name




2. Select TCP/IP (Winsock) for **Connect Using**. If the modem is connected directly to your computer's Ethernet port, put in the **host address** of **192.168.13.31** or the *HOSTPEERIP. If the modem is remote, the **host address** will be the current Internet IP of the Raven X. Change the **port number** to **2332** (default telnet port for the Raven X).


FIGURE 6. HyperTerminal: TCP/IP Settings

Host address:	192.168.13.31
Port number:	2332
Connect using:	TCP/IP (Winsock) ▼

- When HyperTerminal connects to the Raven X, you will be prompted for a password. The default password is **12345**. When you press **Enter**, you should get back a reply of “OK”.

FIGURE 7. HyperTerminal: AT mode via Telnet


- Type **AT** and press **Enter**. You should get a reply of “OK” or “0”.
- To see what you are typing as you type it, you will need to turn on the echo and verbose mode. Type **ATE1V1** and press **Enter**.
If you get a reply of “OK”, then you entered the command successfully. If you get a reply of “0” or “ERROR”, try entering the command again.



Note: You may need to enable Telnet Echo in your terminal emulation application in order to see the commands you type as you type. In HyperTerminal, select *File > Properties*. Select the *Settings* tab. Click the *ASCII Setup* button. Check *Echo typed characters locally*.



Direct Serial Connection

Using HyperTerminal, included with most installations of Microsoft Windows:

Start>All Programs>Accessories>Communications>HyperTerminal

- Choose a name for your connection, such as **Raven X** or **AirLink** (if you want to have a connection saved for both local and remote, it is recommended the connection name reflect the connection type, i.e. Raven X local). The name and icon are only for your own reference so you can find the connection at a later date.



FIGURE 8. HyperTerminal: Connection Name

Enter a name and choose an icon for the connection:

Name:

2. Select COM1 (or the comport to which the modem is connected) for the **Connect Using**.

FIGURE 9. HyperTerminal: Comport Setting

Connect using:

3. Change the **Bits per Second** to 115200 (default), **Data Bits** to 8, **Parity** to None, **Stop Bits** to 1, and **Flow Control** to Hardware.



Note: If you have configured the Raven X for settings different than the defaults for Bits per Second, Data Bits, Parity, and/or Stop Bits, you will need to use your changed settings.

FIGURE 10. HyperTerminal: Comport Settings

Bits per second:

Data bits:

Parity:

Stop bits:

Flow control:

4. Type **AT** and press **Enter**. You should get a reply of “OK” or “0”.
5. To see what you are typing as you type it, you will need to turn on the echo and verbose mode. Type **ATE1V1** and press **Enter**.
If you get a reply of “OK”, then you entered the command successfully. If you get a reply of “0” or “ERROR”, try entering the command again.

Using AT Commands with a Terminal Application

- The following pages list the AT commands, their parameters, and explain what they do. For most commands, when you are entering them using a terminal connection, you will need to preface the command with **AT** (exceptions are noted), i.e. **ATA** which listed as **A**
- Some commands have specific parameters while other commands will take whatever you type.
- Acceptable parameters and/or specific formats are in the parameters column.



- Required variable parameters are denoted with italicized text, example, *Dn*. The *n* is variable and noted in the parameters column.
- Optional parameters are denoted with square brackets [].
- Most commands with parameters can be entered with ? to read the current value (for example, **AT&D?** will respond with “2” if the default has not been changed).
- AT Commands are not case sensitive. A capital “E” is the same as a lower-case “e”.
- When you are using a terminal connection, if you enter a command which is recognized by the Raven X, it will respond with “OK”. If the command is not recognized, the response will be “ERROR”.
- Those commands applicable only to certain model numbers of the Raven X will be noted.



Caution: Symbols listed with commands, such as /, &, or ?, are part of the command and must be included.



AT Command Listing

Symbols

&C	50	*SMTPADDR	64	S7	52
&D	51	*SMTPFROM	64	S82	55
&S	51	*SMTPSEND	65	S83	55
&V	44	*SMTPSTATUS	65	T	
&W	51	*SMTPSUBJ	64	TCPS	53
*CSX1	62	*SMTPUSER	64	TCPT	53
*DATE	46	*SNMPPORT	67	V	
*DATZ	66	*SNMPSECLVL	67	V	50
*DBGCOMLVL	70	*SNMPTRAPDEST	68	X	
*DBGDHCPLVL	70	*SNTP	68	X	50
*DBGETHLVL	70	*SNTPADDR	68	Z	
*DBGIPLVL	70	*STATICIP	47	Z	50
*DBGPPPLVL	71	*STATUSCHK	47		
*DNS	57	*TELNETTIMEOUT	68		
*DNSUPDATE	57	*TPORT	68		
*DNSUSER	57	*UALL	55		
*DOMAIN	58	*UDPLAST	56		
*DPORT	46	*USD	56		
*DU	55	+++	48		
*ENQ	53	+CCID	44		
*ETHMAC	42	+CGQMIN	72		
*HOSTAUTH	60	+CGQREQ	72		
*HOSTMODE	43	+CIMI	44		
*HOSTNETMASK	60	+COPS	72		
*HOSTPAP	46	+ICCID	44		
*HOSTPEERIP	60	A			
*HOSTPRIVIP	60	A	49		
*HOSTPRIVMODE	61	A/	49		
*HOSTPW	61	AIP	54		
*HOSTUID	61	APASSTHRU	63		
*IPMANAGER	58	D			
*IPMGRKEY	59	D	49		
*IPMGRUPDATE	59	DAE	66		
*IPPING	66	E			
*IPPINGADDR	67	E	49		
*MODEMNAME	59	F			
*MSCIUPDADDR	67	FM	69		
*MSCIUPDPERIOD	67	Fn	69		
*NETALLOWZEROIP	46	H			
*NETAPN	72	H	49		
*NETOK	43	HOR	54		
*NETOP	43	I			
*NETPHONE	43	I	42		
*NETPHONE?	46	M			
*NETPW	46	MDhh	54		
*NETRSSI	43	O			
*NETSERV	43	OPRG	45		
*NETSMS2EMAIL	65	Q			
*NETSTATE	43	Q	50		
*NETUID	46	S			
*NETWDOG	67	S0	52		
*PTINIT	62	S221	53		
*PTREFRESH	62	S23	50		
*RESETPERIOD	62	S53	45		
		S60	52		



Information and Status

Most of the commands in the “Info” and “Status” groups as well as other groups have read-only parameters. They only provide information and cannot be changed using Wireless Ace (some can be changed using AT Commands with a terminal application).



Note: Those commands which are not displayed with Wireless Ace may require PassThru mode.

FIGURE 1. Info Group

GROUPS	MODEM DATA			PRINTABLE VIEW
INFO	AT	Name	Value	
STATUS	*NETPHONE	Phone Number	9133784555	
	*DEVICEID	Device ID	0x000003910039C044	
COMMON		Modem EID/IMEI	602C9CCC	
Misc				
Serial	*ETHMAC	Ethernet Mac Address	00143E002656	
TCP		Modem Type	AirLink X	
UDP		Modem Name	602c9ccc	
DNS				
Dynamic IP				
PPP/Ethernet	I1	ALEOS Software Version	V4320 3.0.1.003 Oct 11 2006	
PassThru		Modem Hardware Configuration	090b0004000300000000000000000000	
SMTP		Modem Software Version	p1820200,20212 [Sep 20 2005 15:06:16],	
Other		Modem Hardware Version	MC5720 Rev 1.1 (7)	
Low Power				
Friends				
LOGGING		Boot Version	3.0.1	
		MSCI Version	5	



FIGURE 2. Status Group

GROUPS	MODEM DATA			PRINTABLE VIEW
----- INFO ----- STATUS ----- COMMON Misc Serial TCP UDP DNS Dynamic IP PPP/Ethernet PassThru SMTP Other Low Power Friends ----- LOGGING ----- EDGE/HSDPA	AT	Name	Value	
	*NETIP	Network IP	166.213.203.101	
	*NETSTATE	Network State	Network Ready	
	*NETCHAN	Channel	162	
	*NETRSSI	RSSI (dBm)	-69	
	*NETOP	Current Network Operator	Cingular, 310380	
	+ICCID	SIM ID	89014104200891713451	
	+CIMI	IMSI	310410089171345	
		Host Mode	PPP	
		Host Signl Level	DCD: HIGH DTR: HIGH DSR: HIGH CTS: HIGH RTS: HIGH	
	*NETERR	Network Error Rate	0	
		Network Bytes Sent	172	
		Network Bytes Rcvd	0	
		Host Serial Bytes Sent	7294	
		Host Serial Bytes Rcvd	1016	
		Network IP Packets Sent	3	
		Network IP Packets Rcvd	0	
		Host IP Packets Sent	2	
		Host IP Packets Rcvd	3	
	*NETSERV	Network Service Type	GPRS, EDGE	
	*POWERMODE	PinPoint Low Power Mode State	ON	

I[n]

$n=0$ Product name (for example, Raven X Raven-E).

$n=1$ The Raven X's firmware (ALEOS) version, hardware ID, and copyright.

$n=2$ The internal hardware's firmware version and relevant hardware ID.

$n=3$ The hardware module's unique ID (ESN).

$n=5$ View active profile (the contents of the active registers).

N=5 is not displayed with Wireless Ace.

***DEVICEID?**

The 64-bit device ID the modem uses to identify itself to the cellular network.

***ETHMAC?**

Ethernet Mac Address.

***HOSTMODE?**

The current host mode (AT, PPP, UDP, etc.). If the Raven X is not in AT mode, telnet into the modem to execute this command.

***NETOP?**

The current cellular carrier (for example, Cingular) from the modem's firmware version.

***NETPHONE?**

The modem's phone number (if applicable or obtainable).

***NETRSSI?**

The current RSSI (Receive Signal Strength Indicator) of the Raven X as a negative dBm value.

The same information is displayed with the command **S202?**.

***NETSERV?**

The type of service being used by the modem (for example HSDPA).

***NETSTATE?**

The current network state:

- **Connecting To Network**

The Raven X is in the process of trying to connect to the HSDPA network.

- **Network Authentication Fail**

Authentication to the HSDPA network has failed. Verify settings to activate the Raven X.

- **Data Connection Failed**

The Raven X failed to connect, and it is now waiting a set time interval before it attempts to reconnect. Verify settings to activate the Raven X.

- **Network Negotiation Fail**

Network connection negotiation failed. This is usually temporary and often clears up during a subsequent attempt.

- **Network Ready**

The Raven X is connected to the HSDPA network and ready to send data.

- **Network Dormant**

The Raven X is connected to the HSDPA network, but the link is dormant. It will be woken up when data is sent or received.

- **No Service**

There is no HSDPA network detected.

- **Hardware Reset**

The hardware module is being reset. This is a temporary state.

**&V**

View active profile (the contents of the active registers).

Not displayed with Wireless Ace.

+CCID

Subscriber Identity Module ID

+CIMI

International Mobile Subscriber Identity

+ICCID

Subscriber Identity Module ID

Information Displayed in Wireless Ace without AT Commands Listed

- **Bytes and Packets Received and Sent**
Network traffic for the applicable port.
- **Number of System Resets**
Counter of the number of system resets over the life of the modem or since the configuration was reset.
- **Bad Password Count**
Counter of the number of bad password attempts.
- **IP Reject Count or Log**
Rejected IP Data.
- **Versions of ALEOS, internal hardware, boot, and MSCI**
Versions of internally configured hardware and software.



Misc (Miscellaneous)

This group includes configuration commands which are not specific to other groups.

The commands displayed in Wireless Ace and the results of those commands depends on the model of the modem.

FIGURE 1. Common : Misc

GROUPS	MODEM DATA				PRINTABLE V
----- INFO ----- STATUS ----- COMMON Misc Serial TCP UDP DNS Dynamic IP PPP/Ethernet PassThru SMTP Other Friends ----- LOGGING -----	AT	Name	Value	New Value	
	*DATE	Date and Time	11/17/2006 18:19:33		
	OPRG	Enable Over-the-Air Programing	1		
	*NETPHONE	Phone Number	9133784777		
	*STATICIP	Force Static IP	0.0.0.0		
	*DPORT	Device Port	12345		
	*NETUID	Network User ID			
	*NETPW	Network Password			
	*NETALLOWZEROIP	Allow Last Byte of net IP = Zero	1		
	*HOSTPAP	Request PAP	0		
	\$S3	Destination Address			
	\$S3	Destination Port	0		
	\$S3	Default Dial Code	T		

OPRG=*n*

Enables/disables over-the-air firmware upgrading of the Raven X.

When AirLink releases a new verison of ALEOS, you can upgrade your remote modems with OPRG enabled.

n=0 : Disables

n=1: Enables

\$S3=[*method*][*d.d.d.d*][/*ppppp*]

Destination IP address, port, and method. These are used as defaults for the D (Dial) AT command.

method= **P** : UDP

method=**T** : TCP

method=**N** : Telnet

d.d.d.d=IP address or name

ppppp=the port address



Examples:

ATS53=T192.168.100.23/12345

ATS53=foo.earlink.com

Telnet to the specified IP at port 12345.

ATS53=192.168.100.23/12345

Query the specified IP at port 12345.

ATS53=/12345

Query port 12345.

***DATE=[mm/dd/yyyy],[hh:mm:ss]**

Sets and queries the clock in the unit. Either the date and time can be specified, or simply one of the two can be specified in which case the unspecified value will remain unchanged. The date and time are always specified 24-hour notation.

mm/dd/yyyy = month, day, year

hh:mm:ss = time in 24-hour notation

DPORT=*n

The modem's Device Port which the modem is listening on for inbound packets/data/polls..
Can also be set with the command **S110**.

n=1-65535

HOSTPAP=*n

Use PAP to request the user login and password during PPP negotiation on the host connection.

n=0 : Disable PAP request (Default).

n=1 : Takes user login and password from Windows DUN connection and copies to *NETUID and *NETPW.

NETALLOWZEROIP=*n

Allows the displayed IP address in *NETIP to end in zero (ex. 192.168.1.0).

n=0 : Do not allow

n=1 : Allow

NETPW=*pw

The password that is used to login to Cingular's cellular network, when required.

pw=password

***NETPHONE?**

The modem's phone number, if applicable or obtainable.

NETUID=*uid

The login that is used to login to Cingular's cellular network, when required.



uid=user id (up to 64 bytes)

***STATICIP**=*d.d.d.d*

Set the static IP required to be received from the network. If the modem does not get this IP address from the network, it will reset the internal hardware and try again. The default is 0.0.0.0, which allows any IP address from the network.

d.d.d.d=IP address

Example: **AT*STATICIP=192.168.1.23**



Caution: *STATICIP does not set the IP address of the modem, it merely tells the modem which IP address to expect. If the expected IP address is not granted while registering on the cellular network, the modem will try to register on the network again until it receives that IP address. If your account is set up for a dynamic IP address and you set an address for *STATICIP, you may not be able to register on the network at all since there is no guarantee you will receive the same dynamic IP address again.



Serial

This group includes commands specific to the serial port.

FIGURE 1. Common : Serial

GROUPS	MODEM DATA			PRINTABLE VIEW
----- INFO ----- STATUS ----- COMMON Misc Serial TCP UDP DNS Dynamic IP PPP/Ethernet PassThru SMTP Other Low Power Friends ----- LOGGING	AT	Name	Value	New Value
	S23	Configure Serial Port	115200,8N1	
	\Q	Serial Port Flow Control	2	
	*MODEMHISPEED	Set Internal Serial Link Speed	0	
	S50	Data Forwarding Timeout	1	
	S51	Data Forwarding Character	0	
	E	Command Echo	1	
	V	AT Verbose Mode	1	
	&D	DTR Mode	2	
	S211	DTR Mode	0	
	&S	Assert DSR	1	
	&C	Assert DCD	1	
	*CTSE	Enable CTS to Indicate Network Coverage	0	
	Q	Quiet Mode	0	
	X	Call Progress Result Mode	0	
	*NUMTOIP	Convert 12 digit Number to IP	0	

+++



Note: This command is not preceded by AT nor does it require a carriage return (enter).

There must be an idle time (set by **S50**) on the serial port before and after this command.

The “+” is ASCII 0x2B.

AT Escape sequence.

If the Raven X is in a data mode (any mode other than PassThru), this command causes the modem to re-enter AT command mode.

Cannot be configured in Wireless Ace.



Note: This command does nothing if DAE=1.

**A/**

Note: This command is not preceded by AT.

Re-execute last command.

Cannot be configured in Wireless Ace.

A

Manually answer an incoming connection.

Cannot be configured in Wireless Ace.

D[method][d.d.d.d][/ppppp] or D[method][@name][/ppppp]

Dial a connection to a remote IP and Port using *method*.

Cannot be configured in Wireless Ace.

method=**P** : Establish a UDP connection

method=**T** : Establish a TCP connection

method=**N** : Establish a Telnet connection

d.d.d.d=IP address to contact

ppppp=IP port to contact

Examples:

ATD - Dial (establish) default connection.

ATDP192.168.13.31/2332 - Dial (establish) UDP session to 192.168.13.31, at port 2332.

To end the connection, issue the +++ escape sequence or drop the DTR line (if Ignore DTR **S211=0** or **&D2**).

The default connetion is set in **S53**.

En

Toggle AT command echo mode.

n=**0** : Echo Off

n=**1** : Echo On



Note: All connections types (serial and Telnet) are affected by the echo command.

Hz

Hang-Up Command.

n=**1**: Hang-up

Cannot be configured in Wireless Ace.

**Qn**

The AT quiet-mode setting. If quiet mode is set, there will be no responses to AT commands except for data queried.

n=0 : Off (Default)

n=1 : Quiet-mode on

S23=[speed],[databits][parity][stop bits]

Serial line parameters. The settings take affect after reset.

speed=300 | 1200 | 2400 | 4800 | 9600 | 19200 | 38400 | 57600 | 115200 | 230400

databits=7 or 8

parity=**O** : Odd

parity=**E** : Even

parity=**N** : None

parity=**M**: Mark

stopbits=1 | 1.5 | 2

Example: **ATS23=19200,8N1** (sets modem to 19200, etc.)

Can also be set using **&L=[speed],[databits] [parity][stop bits]**



Note: Databits MUST be 8 data bits for PPP mode.

Vn

Command Response Mode.

n=0 : Terse (numeric) command responses

n=1 : Verbose command responses (Default).

Xn

Extended Call Progress Result mode.

n=0 : Turn off extended result codes (Default).

n=1 : Turn on result codes. This adds the text 19200 to the CONNECT response.

Z

Reset the Raven X.

In Wireless Ace, this command is performed with the Reset option on the toolbar.



Note: This command does nothing if *DATZ=1.

&Cn

Set DCD mode.



n=0 : Always assert DCD.

n=1 : Assert DCD when in a data mode (UDP, TCP, PPP, or SLIP) (Default).

n=2 : Assert DCD when the modem has network coverage.

&D*n*

Set DTR mode.

n=0 : Ignore DTR, same effect as HW DTR always asserted (same as S211=1).

n=2 : Use hardware DTR (same as S211=0).

&S*n*

Set DSR mode.

n=0 : Always assert DSR (Default).

n=1 : Assert DSR when in a data mode (UDP, TCP, PPP, or SLIP) .

n=2 : Assert DSR when the modem has network coverage.

&W

Writes all changed modem settings. If this command is not issued, any modified values will revert back to their previous values at modem reset.

Cannot be configured in Wireless Ace.



TCP

This group includes commands specific to TCP communications.

FIGURE 1. Common : TCP

GROUPS	MODEM DATA			
----- INFO ----- STATUS ----- COMMON Misc Serial TCP UDP DNS Dynamic IP PPP/Ethernet PassThru SMTP Other	AT	Name	Value	New Value
	S0	TCP Auto Answer	0	<input type="text"/>
	S7	TCP Connect Timeout	30	<input type="text"/>
	TCPT	TCP Idle Timeout	0	<input type="text"/>
	TCPS	TCP Idle Timeout Secs	0	<input type="text"/>
	S221	TCP Connect Response Delay	0	<input type="text"/>
	S60	Telnet Echo Mode	1	<input type="text"/>
	*ENQ	Enable ENQ on TCP Connect	0	<input type="text"/>

S0=*n*

This register determines how the Raven X responds to an incoming TCP connection request. The Raven X remains in AT Command mode until a connection request is received. DTR must be asserted (**S211=1** or **&D0**) and the Raven X must be set for a successful TCP connection. The Raven X will send a "RING" string to the host. A "CONNECT" sent to the host indicates acknowledgement of the connection request and the TCP session is established.

n=0 : Off (Default)

n=1 : On

n=2 : Use Telnet server mode on TCP connections.

n=3 : With a Telnet connection, overrides the client's default echo, allowing the server on the host port to perform the echo. CRLF sequences from the telnet client will also be edited to simply pass CRs to the server on the host port.

S7=*n*

Specifies the number of seconds to wait for a TCP connection to be established when dialing out.

n=seconds

S60=*n*

Telnet Client Echo Mode.

n=0 : No Echo

n=1 : Local Echo (Default)

n=2 : Remote Echo

**S221=n**

Connect Delay:

n= 0 - 255

Number of seconds to delay the "CONNECT" response upon establishing a TCP connection.

OR

Number of tenths of seconds to delay before outputting ENQ on the serial port after the CONNECT when the ENQ feature is enabled (see *ENQ).

TCPS=n

TCP connection time-out (TCPS) units. Specifies a time interval upon which if there is no in or outbound traffic through a TCP connection, the connection will be terminated.

n=minutes (TCPS=0) or seconds (TCPS=1)

TCPT=n

TCP connection time-out (TCPT) units. Specifies a time interval upon which if there is no in or outbound traffic through a TCP connection, the connection will be terminated.

n=minutes (TCPT=0) or seconds (TCPT=1)



Note: This value only affects the TCP connection in TCP PAD mode.

***ENQ=n**

Outputs an ENQ [0x05] after the TCP CONNECT delayed by the Delay Connect Response time (**S221**).

n=0 : Disabled (Default).

n=1 : Enables ENQ on CONNECT.



UDP

This group includes commands specific to UDP communications.

FIGURE 1. Common : UDP

GROUPS	MODEM DATA			
----- INFO ----- STATUS ----- COMMON Misc Serial TCP UDP DNS Dynamic IP PPP/Ethernet PassThru SMTP Other Low Power Friends ----- LOGGING	AT	Name	Value	New Value
	MD	Startup Mode Default	03	<input type="text"/>
	S82	UDP Auto Answer	0	<input type="text"/>
	S83	UDP Idle Timeout	0	<input type="text"/>
	HOR	UDP Auto Answer Response	0	<input type="text"/>
	*UDPLAST	UDP Connect Last	0	<input type="text"/>
	AIP	Allow Any IP	0	<input type="text"/>
	*UALL	Allow All UDP	0	<input type="text"/>
	*DU	Dial UDP Always	0	<input type="text"/>
	*USD	UDP Serial Delay	0	<input type="text"/>

AIP=*n*

Allow IP address.

n=0 Allow only the IP address specified in **S53** to connect when UDP auto answer is enabled (**S82**=2).

n=1 Allow any incoming IP address to connect when UDP auto answer is enabled (**S82**=2).



Note: Always subject to any Friends filters that may be defined.

HOR=*n*

Half-Open Response - In UDP auto answer (half-open) mode:

n=0 No response codes when UDP session is initiated.

n=1 RING CONNECT response codes sent out serial link before the data from the first UDP packet.



Note: Quiet Mode must be Off.

MD*hh*

Default power-up mode for the serial port.

When the Raven X is power-cycled, the serial port enters the mode specified by this command after 5 seconds. On startup, typing ATMD0 within 5 seconds changes the mode to normal (AT command) mode.

hh (hex byte)=00 : normal mode



hh=01 : SLIP mode
hh=02 : PPP mode
hh=03 : UDP mode
hh=04 : TCP mode
hh=07 : PassThru mode
hh=0F : PinPoint MDT
hh=13 : Modbus ASCII
hh=23 : Modbus RTU (Binary)
hh=33 : BSAP
hh=63 : Variable Modbus
hh=73 : Reliable UDP
hh=83 : UDP Multicast

See also **S53** to set the port for UDP or TCP.

S82=n

Enables UDP auto answer (half-open) mode.

n=0 : Normal mode
n=2 : Enable UDP auto answer mode.

S83=n

Set or query UDP auto answer idle time-out. If no data is sent or received before the time-out occurs, the current UDP session will be terminated. While a session is active, packets from other IP addresses will be discarded (unless *UALL is set).

n=1 - 255 Time-out in seconds.
n=0 : No idle time-out (Default).

***DU=n**

The dial command always uses UDP, even when using ATDT.

n=0 : Dial using the means specified (default).
n=1 : Dial UDP always, even when using ATDT.



Note: When this parameter is set you cannot establish a TCP PAD connection.

***UALL=n**

Accepts UDP packets from any IP address when a UDP session is active. If there is no UDP session active, an incoming UDP packet will be treated according to the UDP auto answer and AIP settings.

n=0 : No effect (Default).
n=1 : Accept UDP data from all IP addresses when in a UDP session.

***UDPLAST=*n***

If enabled, sets **S53** to the last accepted IP address through UDP auto answer. This can be used in conjunction with **MD3** so that when there is no UDP session, new ethernet host data will cause a connection to be restored to the last IP accepted through UDP auto answer. .

n=**0** : Does not change **S53** setting. (Default).

n=**1** : Set **S53** to the last accepted IP.



Note: This does not change the **S53** setting in NVRAM. If the modem is reset, the original **S53** setting will be restored from NVRAM.

USD=*n

Waits the specified delay before sending the first UDP packet and the subsequent UDP packets out to the Ethernet port.

n=**1 - 255** Delay in 100ms units, from 100 ms to 25.5 sec.

n=**0** : No UDP packet delay (Default).



DNS

This group includes commands specific to the modem being able to use domain names instead of IP addresses for other configuration options.

FIGURE 1. Common : DNS

GROUPS	MODEM DATA			
COMMON	AT	Name	Value	New Value
Misc	*DNS1	Modem DNS Server 1	209.183.48.10	
Serial	*DNS2	Modem DNS Server 2	209.183.48.11	
TCP				
UDP				
DNS	*DNSUSER	Use Alternate DNS	0.0.0.0	<input type="text"/>
Dynamic IP	*DNSUPDATE	DNS Updates	0	<input type="text"/>
PPP/Ethernet				
PassThru				

*DNS n

Queries the DNS addresses. Cingular provides the DNS addresses while your modem is registering on their network.

$n=1$ or 2 First and second DNS address.

$d.d.d.d$ = IP of domain server

*DNSUPDATE= n

Indicates whether the modem should send DNS updates to the DNS server specified by *DNSUSER. These updates are as per RFC2136. They are not secure and are recommended only for a private network. In a public network, the IP Logger services should be used instead.

$n=0$: DNS updates disabled (Default).

$n=1$: DNS updates enabled.

*DNSUSER= $d.d.d.d$

Sets a user-provided DNS to query first when performing name resolutions in the modem.

$d.d.d.d$ = IP of domain server



Dynamic IP

This group includes commands specific to dynamic DNS. Dynamic DNS allows the Raven X to use a dynamic IP (can change each time you connect) account but still allow you to use a fully qualified domain name to contact the Raven X using IP Manager (page 14) running on a server with a dynamic DNS updater.

FIGURE 1. Common : Dynamic IP

GROUPS	MODEM DATA			
-----	AT	Name	Value	New Value
INFO	*MODEMNAME	Modem Name		
STATUS	*DOMAIN	Domain	eaalink.com	
COMMON	*IPMANAGER1	IP Manager Server 1 (IP Adrs)		
Misc	*IPMGRUPDATE1	IPMServer1 Update (Minutes)	0	
Serial	*IPMGRKEY1	IPMServer1 Key	*****	
TCP	*IPMANAGER2	IP Manager Server 2 (IP Adrs)		
UDP	*IPMGRUPDATE2	IPMServer2 Update (Minutes)	0	
DNS	*IPMGRKEY2	IPMServer2 Key	*****	
Dynamic IP				
PPP/Ethernet				
PassThru				
SMTP				
Other				
Low Power				
Friends				

*DOMAIN=[name]

Domain (or domain zone) of which the Raven X is a part. This value is used during name resolutions if a fully qualified name is not provided and also for DNS updates. This value can be up to 20 characters long.

name = domain name (i.e. eaalink.com)

If ***DOMAIN=eaalink.com**, then when ATDT@remote1 is entered, the fully qualified name remote1.eaalink.com will be used to perform a DNS query to resolve the name to an IP address.



Note: Only letters, numbers, hyphens, and periods can be used in a domain name.

*IPMANAGER n =[name]

Sets a domain name or IP address to send IP change notifications to. Up to two independent IP Manager servers can be set, using either AT*IPMANAGER1 or AT*IPMANAGER2. Updates to a server can be disabled by setting that entry to nothing (for example, "AT*IPMANAGER1=").

n=1 : First IP Manager server.

n=2 : Second IP Manager server.

name = domain name



IPMGRKEYn*=[key]

Sets the 128-bit key to use to authenticate the IP update notifications. If the key's value is all zeros, a default key will be used. If all the bytes in the key are set to FF, then no key will be used (i.e. the IP change notifications will not be authenticated). AT*IPMGRKEY1 is used to set the key to use with AT*IPMANAGER1, while AT*IPMGRKEY2 is used to the key with AT*IPMANAGER2.

n=1 : First IP Manager server.

n=2 : Second IP Manager server.

key=128-bit key in hexadecimal [32 hex characters]

IPMGRUPDATEn*=*m*

Sets the number of minutes to periodically send an IP update notification to the corresponding server. This will occur even if the IP address of the Raven X doesn't change.

*IPMGRUPDATE1 is used to set the refresh rate to *IPMANAGER1, while

*IPMGRUPDATE2 is used with *IPMANAGER2.

n=1 : First IP Manager server.

n=2 : Second IP Manager server.

m=0, 5-255 Number of minutes to send an update.

If the value is set to 0, then periodic updates will not be issued (i.e. IP change notifications will only be sent when the IP actually changes).

***MODEMNAME**=[name]

Name of the Raven X (up to 20 characters long) to use when performing IP address change notifications to IP Manager. The value in *DOMAIN provides the domain zone to add to this name.

name = domain name (i.e. eairlink.com)

Example: if *MODEMNAME=mymodem and *DOMAIN=eairlink.com, then the modem's fully qualified domain name is mymodem.eairlink.com.

Automatically Generated Names:

- **#I3** - The ESN/IMEI will be used as the name.
- **#NETPHONE** - The phone number will be used as the name.



Note: Each modem using IP Manager needs a unique name. Two modems cannot be called "mymodem". One could be "mymodem1" with the other as "mymodem".



PPP/Ethernet

This group includes commands specific to PPP or Ethernet connections between the Raven X and a connected device.

FIGURE 1. Common : PPP/Ethernet

GROUPS	MODEM DATA			PRINTABLE
-----	AT	Name	Value	New Value
INFO	*HOSTPRIVMODE	Use Private IP	0	<input type="text"/>
STATUS	*HOSTPRIVIP	Host Private IP	0.0.0.0	<input type="text"/>
COMMON	*HOSTPEERIP	Modem Local IP	192.168.13.31	<input type="text"/>
Misc	*HOSTNETMASK	Host network mask	0.0.0.0	<input type="text"/>
Serial	*HOSTAUTH	Host Authentication Mode	0	<input type="text"/>
TCP	*HOSTUID	Host User ID	ZCFzUUeLycb2ug01L+3Ik==	<input type="text"/>
UDP	*HOSTPW	Host Password	ZCFzUUeLycb2ug01L+3Ik==	<input type="text"/>
DNS				
Dynamic IP				
PPP/Ethernet				
PassThru				
SMTP				
Other				

*HOSTAUTH=*n*

Host Authentication Mode: Use PAP or CHAP to request the user login and password during PPP or CHAP negotiation on the host connection. The username and password set in *HOSTUID and *HOSTPW will be used.

n=0 : Disable PAP or CHAP request (Default).

n=1 : PAP and CHAP.

n=2 : CHAP

*HOSTNETMASK=*n.n.n.n*

Subnet mask for the host interface. Allows communication with a subnet behind the host interface.

n.n.n.n = subnet mask, example 255.255.255.0

*HOSTPEERIP=*d.d.d.d*

Set or query the IP address that can be used to directly contact the Raven X once a HSDPA connection is established. If this value is not specified, 192.168.13.31 will be used.

d.d.d.d=local or peer IP of modem



Note: This is not normally used nor needed by user applications.

*HOSTPRIVIP=*d.d.d.d*

Set or query the private IP address that is to be negotiated by the HSDPA connection if *HOSTPRIVMODE =1.



d.d.d.d=IP Address

HOSTPRIVMODE=*n

Set or query whether a private or public (network) IP is to be used when the Host initiates a HSDPA connection to the modem.

n=**0** : Public (network) IP Mode: When the Host initiates a PPP connection, the host will be given the network IP address that was obtained from Cingular while registering on the network. If the network issues a new IP address, the HSDPA connection will be closed (since the IP address has changed) and has to be re-initiated. (default).

n=**1** : Private IP Mode: When the Host initiates a HSDPA connection, the host will be given the IP address specified in *HOSTPRIVIP. The modem will then perform 1 to 1 NAT-like address translation, which shields the Host from network IP changes.

HOSTPW=*string

Host Password for PAP, or CHAP, or PPPoE.

string=password

HOSTUID=*string

Host User ID for PAP, or CHAP, or PPPoE.

string=user id (up to 64 bytes)



PassThru

PassThru Mode is used to communicate directly to the Raven X's internal hardware.



Caution: While the modem is in PassThru mode, ALEOS is disabled. If you need to connect to the Raven X while it is in PassThru mode, you will need to do so with a terminal application. Not all commands are available while the modem is in PassThru mode.

FIGURE 1. Common : PassThru

GROUPS	MODEM DATA			
DNS Dynamic IP PPP/Ethernet PassThru SMTP Other Low Power Friends	AT	Name	Value	New Value
	*PTINIT	Passthrough Init String	<input type="text"/>	<input type="text"/>
	*PTREFRESH	Passthrough Init Refresh (Minutes)	<input type="text" value="0"/>	<input type="text"/>
	*RESETPERIOD	Modem Reset Period (Hours)	<input type="text" value="0"/>	<input type="text"/>
LOGGING	*CSX1	Passthrough Echo	<input type="text" value="0"/>	<input type="text"/>

*CSX1=*n*

n=0 : Data will be passed to the host.

n=1 : PASSTHRU mode will echo all host received data and will not pass the data to the modem while the modem is not asserting DCD.



Note: If the modem is asserting DCD, data will be passed from the host to the modem as it normally is when *CSX1=0.

*PTINIT=*string*

Any AT Command string to be passed to the OEM module before entering PASSTHRU mode, e.g. AT&S1V1, etc.

string=AT command(s)

*PTREFRESH=*n*

Number of minutes of inactivity in PASSTHRU mode to resend the *PTINIT string to the hardware module.

n=1-255 minutes

n=0 : Disabled

*RESETPERIOD=*n*

In PASSTHRU mode, modem will be reset after this period if no data has been sent or received. Value is in hours.

n=1-255 hours

n=0 : Disabled



\APASSTHRU



Caution: This mode is not available through the remote AT telnet server. You will need to connect to the Raven X with it connected directly to your computer.

Sets the modem operation to pass through mode. This mode will pass any characters received on the Ethernet port directly to the internal hardware module and output any characters from the internal hardware module out the Ethernet port. This allows direct access/configuration of the hardware module. Once this mode is entered, the unit must be physically reset to return to normal operation.

This command is not available in Wireless Ace.



Note: It may take up to 30 seconds for the hardware module to respond after CONNECT is output.



SMTP (including SMS)

This group includes commands specific to messaging.

SMS (Short Message Service) is a way to send messages via Cingular's cellular network.



Caution: Your account with Cingular may not support message sending with SMS.

FIGURE 1. Common : SMTP

GROUPS	MODEM DATA			
DNS	AT	Name	Value	New Value
Dynamic IP				
PPP/Ethernet				
PassThru				
SMTP	*SMTPADDR	SMTP Server IP Address	<input type="text"/>	<input type="text"/>
Other	*SMTPFROM	From email address	<input type="text"/>	<input type="text"/>
Low Power	*SMTPUSER	User Name (optional)	<input type="text"/>	<input type="text"/>
Friends				
LOGGING	*SMTPPW	Password (optional)	*****	<input type="text"/>
	*SMTPSUBJ	SMTP Message Subject	<input type="text"/>	<input type="text"/>

*SMTPADDR=*name*]

Specify the IP address or Fully Qualified Domain Name (FQDN) of the SMTP server to use.

d.d.d.d=IP Address

name=domain name

Maximum: 40 characters.

*SMTPFROM=*email*

Sets the email address from which the SMTP message is being sent.

email= email address

Maximum: 30 characters.

*SMTPSUBJ=*subject*

Allows configuration of the default Subject to use if one isn't specified in the message by providing a "Subject: xxx" line as the initial message line.

subject= SMTP message subject

*SMTPUSER=*user*

The email account username to authenticate with the SMTP server (*SMTPADDR) for sending email.

user= username



Maximum: 40 characters.



Note: Not required to use SMTP settings but may be required by Cingular.

Messaging related AT Commands not Available through Wireless Ace

NETSMS2EMAIL=*n

Specify the SMS/E-mail server number. This maybe necessary to send an SMS message to an email address .

n=SMS/E-mail server

***SMTPSEND=[*email*][*body*]**

Sends an email to the address specified, followed by the body of the email message.

email= email address

body= message body

The email message is terminated and sent by entering a . or **Ctrl-Z** on an empty line.

See also *SMTPSUBJ, *SMYPFROM, and *SMTPADDR.

***SMTPSTATUS?**

Returns the status of the last issued SMTP message (*SMTPSEND). If no status is available **0** is returned. Once read, the status is cleared out.

The status codes returned come from the SMTP server to which that the modem sent the request. Unless the receiving server is not standard, they follow the RFC for SMTP.

Example: 354 = send in progress, 250 = sent ok.



Other

The commands in this group are not specific to the other group categories.

FIGURE 1. Common : Other

GROUPS	MODEM DATA				PRINT
----- INFO ----- STATUS ----- COMMON Misc Serial TCP UDP DNS Dynamic IP PPP/Ethernet PassThru SMTP Other Low Power Friends ----- LOGGING	AT	Name	Value	New Value	
	*IPING	Keepalive Ping Time	0		
	*IPINGADDR	Keepalive Ping Address	66.166.144.18		
	*MSCIUPDADDR	Status Update Address	/0		
	*MSCIUPDPERIOD	Status Update Period (Seconds)	0		
	*TPORT	AT Telnet Port	2332		
	*TELNETTIMEOUT	AT Telnet Port Timeout (Minutes)	2		
	DAE	Disable AT Escape	0		
	*DATZ	Disable ATZ Reset	0		
	*SNTP	Enable time update	0		
	*SNTPADDR	SNTP Server Address			
	*NETWDOG	Network Connection Wait	20		
	*SNMPPORT	SNMP Port	0		
	*SNMPSECLVL	SNMP Security Level	0		
	*SNMPTRAPDEST	SNMP Trap Destination IP	/0		
	*SNMPCOMMUNITY	SNMP Community String	public		

DAE=*n*

Disable AT Escape Sequence detection.

n=0 : Enable +++ AT escape sequence detection.

n=1 : Disable +++ AT escape sequence detection.

*DATZ=*n*

Enables or disables reset on ATZ.

n=0 : Normal Reset (Default)

n=1 : Disable Reset on ATZ

*IPING=*n*

Set the period to ping (if no valid packets have been received) a specified address (*IPINGADDR) to keep the modem alive (online).

n=15-255 minutes



n=0 : Disable pinging (default)

15 minutes is the minimum interval which can be set for Keepalive.

See also *MINXMIT which can override this value.

***IPPINGADDR=[*d.d.d.d*][*name*]**

Set the IP address or valid internet domain name for the Raven X to ping to keep itself alive (online). *IPPING must to be set to a value other than 0 to enable pinging.

d.d.d.d=IP address

name= domain name

***MSCIUPDADDR=*name*[/*port*]**

Modem Status Update Address - where Name/Port is the domain name and port of the machine where the modem status updates will be sent. The Raven X's status parameters are sent in an XML format.

name=domain name

port=port

MSCIUPDPERIOD=*n

Modem Status Update Period - where n defines the update period in seconds.

n=1-255 seconds

n=0 : Disabled.

NETWDOG=*n

Network connection watchdog: The number of minutes to wait for a network connection. If no connection is established within the set number of minutes, the Raven X resets.

n=minutes Default = 20 min.

n=0 : Disabled.

SNMPCOMMUNITY=*n

The SNMP Community String acts like a password to limit access to the modem's SNMP data.

n=a string of no more than 20 characters (default = public).

SNMPPORT=*n

This controls which port the SNMP Agent listens on.

n=1-65535

n=0 : SNMP is disabled.

SNMPSECLVL=*n

Selects the security level requirements for SNMP communications as follows:

n=0 : No security required. SNMPv2c and SNMPv3 communications are allowed.



n=1 : Authentication equivalent to “authNoPriv” setting in SNMPv3. SNMPv3 is required to do authentication, SNMPv2c transmissions will be silently discarded.

n=2 : Authentication and encryption, equivalent to “authPriv” setting in SNMPv3. SNMPv3 is required to do authentication and encryption, SNMPv2c and SNMPv3 authNoPriv transmissions will be silently discarded. Messages are both authenticated and encrypted to prevent a hacker from viewing its contents.

***SNMPTRAPDEST=host/[port]**

Controls destination for SNMP Trap messages.

host=IP address

port=TCP port

If port is 0 or host is empty, traps are disabled.

Traps are sent out according to the SNMP security level (i.e. if the security level is 2, traps will be authenticated and encrypted). Currently, the only trap that can be generated is linkup.

SNTP=*n

Enables daily SNTP update of the system time.

n=0 : Off

n=1 : On

***SNTPADDR=[*d.d.d.d*][*name*]**

SNTP Server IP address, or fully-qualified domain name, to use if *SNTP=1.

d.d.d.d=IP

name=domain name

If blank, **time.nist.gov** is used.

TELNETTIMEOUT=*n

Telnet port inactivity time out.

n=minutes

By default, this value is set to close the AT telnet connection if no data is received for 2 minutes.

TPORT=*n

Sets or queries the port used for the AT Telnet server. If 0 is specified, the AT Telnet server will be disabled. The default value is **2332**.

n=1-65535

n=0 : Disabled.



Friends

Friends Mode can limit access to the Raven X from Cingular's network and the Internet. Friends Mode is a limited form of security, a basic firewall.



Note: Friends mode does not block any traffic from the cellular network, wanted or not. Friends Mode will only prevent the Raven X from forwarding data from those not on the Friends List. It does not prevent data from traversing the network to the modem which is still billable traffic.

FIGURE 1. Common : Friends

GROUPS	MODEM DATA			
INFO	AT	Name	Value	New Value
STATUS	FM	Friends Mode	0	<input type="text"/>
COMMON	F0	Friends List IP0	0.0.0.0	<input type="text"/>
Misc	F1	Friends List IP1	0.0.0.0	<input type="text"/>
Serial	F2	Friends List IP2	0.0.0.0	<input type="text"/>
TCP	F3	Friends List IP3	0.0.0.0	<input type="text"/>
UDP	F4	Friends List IP4	0.0.0.0	<input type="text"/>
DNS	F5	Friends List IP5	0.0.0.0	<input type="text"/>
Dynamic IP	F6	Friends List IP6	0.0.0.0	<input type="text"/>
PPP/Ethernet	F7	Friends List IP7	0.0.0.0	<input type="text"/>
PassThru	F8	Friends List IP8	0.0.0.0	<input type="text"/>
SMTP	F9	Friends List IP9	0.0.0.0	<input type="text"/>
Other				
Low Power				
Friends				
LOGGING				
TELEMETRY				
ADDR LIST				

FM=*n*

Friends Mode - Only allow specified IPs to access the Raven X.

n=0 : Disable Friends mode

n=1 : Enable Friends mode - Only packets from friends will be accepted (see below); packets from other IP addresses are ignored.

F*n*=[*d.d.d.d*]

Friends mode IP address.

n=0 - 9 Friends list index .

d.d.d.d =IP address

255 = allow any number 0-255

Example: 166.129.2.255 allows access by all IPs in the range 166.129.2.0-166.129.2.255.

ATF? will return a list of all the current *F_n* settings.



Logging

This group includes commands specific to the internal log.

The commands displayed in Wireless Ace and the results of those commands depends on the model of the modem.

FIGURE 1. Logging

GROUPS	MODEM DATA			
LOGGING	AT	Name	Value	New Value
	*DBGPPPLVL	PPP Logging Detail	1	<input type="text"/>
	*DBGIPLVL	IP Logging Detail	0	<input type="text"/>
	*DBGCOMLVL	COM Port Logging Detail	0	<input type="text"/>
	*DBGETHLVL	Ethernet Logging Detail	0	<input type="text"/>
	*DBGDHCPLVL	DHCP Logging Detail	0	<input type="text"/>

DBGCOMMLVL=*n

Set the logging level for the host or module COM port.

n=0 : No logging

n=1 : Host COM

n=2 : Module COM

DBGDHCPLVL=*n

Enable or disable internal DHCP logging.

n=0 : No logging

n=1 : Log DHCP events.

DBGETHLVL=*n

Sets the logging level for the Ethernet port.

n=0 : No logging

n=1 : Log errors (i.e. invalid/corrupt packets, etc.).

n=2 : Log the header of all received packets. Note that this can quickly exhaust available space for the event log.

DBGIPLVL=*n

Sets the logging level for the IP subsystem.

n=0 : No logging

n=1 : Log errors (i.e. invalid/corrupt packets, etc.).

n=2 : Log the header of all received packets. Note that this can quickly exhaust available space for the event log.



n=3 : Log the header of all received and sent packets. Note that this can quickly exhaust available space for the event log.

DBGPPPLVL=*n

Sets the logging level for the PPP stack.

Enables logging at different levels of detail.

n=0 : No logging

n=1 : Log client events (default)

n=2 : Log server events

n=3 : Log client and Server events



EDGE/HSDPA

This group includes commands specific to HSDPA, EDGE and GPRS.

FIGURE 1. EDGE/HSDPA

GROUPS	MODEM DATA				PRINTABLE V
PassThru	AT	Name	Value	New Value	
SMTP	*NETAPN	Set APN	internet		
Other	+COPS	Set Carrier [operator] Selection	0		
Low Power	+CGQREQ	Set Quality of Service Profile			
Friends	+CGQMIN	Minimum Acceptable Quality of Service Profile			

LOGGING					

EDGE/HSDPA					

+CGQMIN

Minimum Acceptable Quality of Service Profile.

Change should be at carrier's request. Normally not required to be changed.

+CGQREQ

Set Quality of Service Profile.

Change should be at carrier's request. Normally not required to be changed.

+COPS=*mode*,*[format]**[,oper]*

Manually specify an operator. Refer also to *NETOP.

mode=0 : Automatic - any affiliated carrier [default].

mode=1 : Manual - use only the operator <oper> specified.

mode=4 : Manual/Automatic - if manual selection fails, goes to automatic mode.

format=0 : Alphanumeric ("name") (G310 must use this format).

format=2 : Numeric

oper="name"

PPPoE: Point to Point Protocol over Ethernet

PPPoE (Point-to-Point Protocol over Ethernet) allows a point-to-point connection while using Ethernet. Just like the dial up protocol on which it is based, PPPoE uses traditional username and password authentication to establish a direct connection between two Ethernet devices on a network (such as your Raven X and your computer or router).

Application examples for PPPoE with your Raven X:

- Backup connectivity solution for your network
- Password restricted Internet connection
- Individualized Internet connection on a LAN

PPPoE (PPP over Ethernet) Configuration



You only need to configure a PPPoE connection on your computer if you will be connecting from the computer to the Raven X on a LAN sharing the same subnet. You may need to use Private Mode in the modem to configure its IP address to be available on the LAN.



Note: If you are using the Raven X connected to a router as a back up Internet connection for your network, you should configure the router to use the PPPoE connection and not the individual computers. Only one computer, router, or other network device at a time can connect to the Raven X using PPPoE.


To configure a PPPoE connection on Microsoft Windows XP, 2000 or NT, you will need administrator privileges to the computer you are configuring or access granted by an administrator on the network to add/remove devices to your computer.

Configuring your Raven X for PPPoE

1. Connect your Raven X directly to your computer or to a hub to which your computer is also connected .
2. Start Wireless Ace: *Start > All Programs > AirLink Communications > Wireless Ace 3G > Wireless Ace 3G*
 - a. Click the **Connect** button and select **UDP**. Enter the IP address and password (the default IP is **192.168.13.31** and the default password is **12345**).



FIGURE 1. Wireless Ace: Connect



b. When Wireless Ace has connected to your Raven X, from the groups on the left, select **PPP/Ethernet** under **Common**.

FIGURE 2. Wireless Ace: PPP/Ethernet

GROUPS	MODEM DATA				PRINTABLE V
INFO	AT	Name	Value	New Value	
STATUS	*HOSTPRIVMODE	Use Private IP	0		
COMMON	*HOSTPRIVIP	Host Private IP	0.0.0.0		
Misc	*HOSTPEERIP	Modem Local IP	192.168.13.31		
DNS	*HOSTNETMASK	Host network mask	0.0.0.0		
Dynamic IP	*HOSTAUTH	Host Authentication Mode	0	2 - Chap	
PPP/Ethernet	*HOSTUID	Host User ID	ZCFzUUeLycb2ug01L+3Ik==	User Name (encrypted)	
PassThru	*HOSTPW	Host Password	ZCFzUUeLycb2ug01L+3Ik==	Password (encrypted)	
SMTP	*DHCPSEVER	DHCP Server Mode	2	2 - Enabled/LAN	
Other					
Low Power					
Friends					
LOGGING					



Note: Wireless Ace shows the existing values for *HOSTUID and *HOSTPW encrypted and character padded.

3. Configure *HOSTAUTH, *HOSTUID, and *HOSTPW.

- Change ***HOSTAUTH** to **2**.
- Enter a username for ***HOSTUID** for the PPPoE connection.
- Enter a password for ***HOSTPW** for the PPPoE to connection.



If you leave *HOSTUID and *HOSTPW blank, any computer or device can connect to the Raven X using PPPoE.

Optional Configure *MODEMNAME.



PPPoE connections can use a Service Name to differentiate PPPoE devices. You can use Wireless Ace to give your Raven X a name.

- a. In Wireless Ace, select **Dynamic IP** from the groups on the left.
- b. Enter a name for ***MODEMNAME**, such as [Raven X](#) or the [ESN](#).

FIGURE 3. Wireless Ace: *MODEMNAME

GROUPS	MODEM DATA				PRINT
TCP UDP DNS Dynamic IP PPPoE/Ethernet	AT	Name	Value	New Value	
	*MODEMNAME	Modem Name		AirLink Modem	




The name you choose will not affect the connection but may need to be configured in PPPoE settings for the router, device or computer you will be connecting to your Raven X.

4. Write the configured settings to your Raven X.

- a. Click the **Write** button on the tool bar of Wireless Ace and wait for the message “Write Successful” to appear in the status bar.

FIGURE 4. Wireless Ace: Write



- b. Press the modem Reset button on the front of the modem. Wait until the modem **Network** indicator is lit and the modem has once again registered on the network.

FIGURE 5. Raven X Reset Button


Configuring a PPPoE Connection in Windows

1. Create a new network connection.

- a. Select **Start > Connect To > Show All Connections**. This will open the **Network Connections** window.



FIGURE 6. Show All Connections



b. Select **Create a New Connection** under *Network Tasks* in the menu area on the left. Select **Next** to start installing and configuring the PPPoE connection.

FIGURE 7. Network Connections







FIGURE 8. New Connection




c. Select **Connect to the Internet** and then select **Next**.

FIGURE 9. Connection Type



d. Select **Set up my connection manually** and then select **Next**.

FIGURE 10. Preparing the Internet Connection



e. Select **Connect using a broadband connection...** and select **Next**.



FIGURE 11. Internet Connection

☐ **Connect using a dial-up modem**
 This type of connection uses a modem and a regular or ISDN phone line.

☒ **Connect using a broadband connection that requires a user name and password**
 This is a high-speed connection using either a DSL or cable modem. Your ISP may refer to this type of connection as PPPoE.

☐ **Connect using a broadband connection that is always on**
 This is a high-speed connection using either a cable modem, DSL or LAN connection. It is always active, and doesn't require you to sign in.

f. Type in a name for the connection, such as **AirLink PPPoE Connection**. Select **Next**.



The name provided here will not effect the connection in any way. It is only a label for the icon. It can be the name of your Wireless Service Provider (Cingular), your modem (Raven X), or any other designation for the connection.

FIGURE 12. Connection Name

Type the name of your ISP in the following box.

ISP Name

AirLink PPPoE Connection

The name you type here will be the name of the connection you are creating.

Optional: If you have multiple users configured for your computer, you may be prompted for *Connection Availability*. If you select **My use only**, the account currently logged on will be the only one able to use this DUN connection.

g. Enter the user name and password you configured for ***HOSTUID** and ***HOSTPW** above. If you want to allow others to use the same login for the modem, select **Use this account name and password...** Select **Next** to continue.

FIGURE 13. Account Information

Type an ISP account name and password, then write down this information and store it in a safe place. (If you have forgotten an existing account name or password, contact your ISP.)

User name: Same as *HOSTUID configured earlier

Password: Same as *HOSTPW configured earlier

Confirm password:


☒ Use this account name and password when anyone connects to the Internet from this computer

☐ Make this the default Internet connection



h. If you want to add a shortcut for this connection to your desktop, check **Add a shortcut...** Select **Finish** to exit the *Network Connection Wizard*.

FIGURE 14. Finish



2. Configure the connection.

After you complete the New Connection Wizard, there are a few more things you will want to configure in the connection.




FIGURE 15. Connect



a. When the **Connect** window opens, select **Properties**.


Optional: On the **General** tab, if you gave the modem a name with ***MODEMNAME** above, you can type in that name as the **Service Name**.

FIGURE 16. Connection Properties



b. Select **Networking**. Select **Settings**. Remove the checks from all three PPP settings. Select **OK**.

FIGURE 17. Connection Properties - PPP Settings





Optional: You may want to check the **Options** tab and change the settings for applications you might be using. The default options are generally applicable for most uses.

c. Unless specifically directed to do so by Support or your network administrator, you should not need to make any changes to the options on the **Networking**, **Security**, or **Advanced** tabs.

Connecting to the Internet with PPPoE

Now the PPPoE connection can be run and a data connection can be established.


1. Connect your computer and the modem to the same local network using a hub or a switch.



Note: It is not recommended to connect your computer directly to the modem without a local network.


2. Start the PPPoE by **Start > Connect To > AirLink PPPoE** (or whatever you named the connection). It will be listed on your Network Connections window under the heading *Broadband*.

FIGURE 18. MS Windows XP: Connect



- a. Enter the **User name** and **Password** you configured for *HOSTUID and *HOSTPW above.
- b. Select **Connect** to connect to the modem and the Internet. When you're connected, an icon should appear in the system tray showing the connection status.

FIGURE 19. MS Windows XP: Connect





Configuring your router for PPPoE with the Raven X

If your network router has PPPoE discovery, the Raven X will be discovered on the intranet through PPPoE discovery process, which uses broadcast Ethernet packets. Once found, the Raven X can be designated as the primary or failover connection.

Your network router should be configured to make a PPPoE connection using the username and password configured with ***HOSTUID** and ***HOSTPW**, and the service name configured with ***MODEMNAME** (*optional*). It should also be configured to re-route packets through the connection with the Raven X.

Simple Network Management Protocol (SNMP)

The Raven X can be configured as an SNMP agent and supports SNMPv2c and SNMPv3.

SNMP Overview

The Simple Network Management Protocol (SNMP) was designed to allow remote management and monitoring of a variety of devices from a central location. The SNMP management system is generally composed of agents (such as your Raven X, a router, a UPS, a web server, a file server, or other computer equipment) and a Network Management Station (NMS) which monitors all the agents on a specific network. Using the management information base (MIB), an NMS can include reporting, network topology mapping, tools to allow traffic monitoring and trend analysis, and device monitoring.

Authentication ensures SNMP messages coming from the agent, such as the Raven X, have not been modified and the agent may not be queried by unauthorized users. SNMPv3 uses a User-Based Security Model (USM) to authenticate and, if desired or supported, message encryption. USM uses a user name and password specific to each device.

Management Information Base (MIB)

The management information base (MIB) is a type of database used to compile the information from the various SNMP agents. Reports from various agents, such as the Raven X, are sent as data in form designed to be parsed by the NMS into its MIB. The data is hierarchical with entries addressed through object identifiers.

SNMP Traps

The trap is a “snap-shot” of the settings and status of the Agent’s device which is sent as a report to the NMS in a form that can be parsed and stored in the MIB.

Raven X SNMP Configuration

To configure your Raven X to work as an SNMP agent, you can use either Wireless Ace, or a terminal connection to configure the modem using AT commands (page 34). In Wireless Ace, the SNMP commands are all on the **Other** menu option.



There are only three commands to set for SNMP in the Raven X: the listening port, the security level, and the trap destination.

Listening Port

*SNMPPORT sets the port for the SNMP agent to listen on. If set to zero, default, SNMP is disabled.

FIGURE 1. Wireless Ace: *SNMPPORT

SMTP	AT	Name	Value	New Value
Other	*SNMPPORT	SNMP Port	0	
Low Power				



Note: SNMP generally uses port 161, however most Internet providers (including cellular) block all ports below 1024 as a security measure. You should be able to use a higher numbered port such as 10161.

Security Level

*SNMPSECLVL sets the security level and which version of SNMP communications are used.

FIGURE 2. Wireless Ace: *SNMPSECLVL

SMTP	AT	Name	Value	New Value
Other	*SNMPSECLVL	SNMP Security Level	0	
Low Power				

0 - No security required. SNMPv2c and SMNPv3 communications are allowed.

1 - Authentication required. SNMPv3 is required to do authentication and SNMPv2c transmissions will be silently discarded. Authentication is equivalent to the authNoPriv setting in SNMPv3.

2 - Authentication required and messages are encrypted. SNMPv3 is required to do authentication. SNMPv2c and SNMPv3 authNoPriv transmissions will be silently discarded. Authentication and encryption is equivalent to the authPriv setting in SNMPv3.

User Name and Password

The user name is '*user*'. The user name cannot be changed. The Raven X's password is used as the SNMP password (default is '*12345*').




Note: The eight-character password requirement for SMNPv3 is not enforced by the Raven X's Agent to allow the default password to function. Your SNMP administrator or MIS may require you to change to a more secure and/or longer password.

To change the password in the Raven X, select **Modem** from the top menu line in Wireless Ace.



FIGURE 3. Wireless Ace: Changing the Raven X Password - Menu Option



The current password will be pre-entered. As you type the new password and confirm it, the characters you type will be obscured by “x”. For the password, you can use numbers, letters, and/or punctuation.



Caution: The password is case sensitive. “drowssaP” is not the same as “drowssap”.

Trap Destination

*SNMPTRAPDEST needs to be set with the destination IP and port. If either are set to zero or empty, SNMP traps are disabled.

FIGURE 4. Wireless Ace: *SNMPPORT

SMTP	AT	Name	Value	New Value
Other	*SNMPTRAPDEST	SNMP Trap Destination IP	/0	
Low Power				



Note: Traps are sent out according to the SNMP security level (i.e. if the security level is 2, traps will be authenticated and encrypted). Currently, the only trap supported is **LinkUp**.

SNMP MIB Definition for AirLink

```
AIRLINK-MIB DEFINITIONS ::= BEGIN
```

```
IMPORTS
```

```
ObjectName FROM SNMPv2-SMI
```

```
MODULE-COMPLIANCE FROM SNMPv2-CONF;
```

```
org OBJECT IDENTIFIER ::= { iso 3 }
```

```
dod OBJECT IDENTIFIER ::= { org 6 }
```



```
internet OBJECT IDENTIFIER ::= { dod 1 }
private OBJECT IDENTIFIER ::= { internet 4 }
enterprises OBJECT IDENTIFIER ::= { private 1 }

airlink OBJECT IDENTIFIER ::= { enterprises 20542 }
general OBJECT IDENTIFIER ::= { airlink 1 }
common OBJECT IDENTIFIER ::= { airlink 2 }
status OBJECT IDENTIFIER ::= { airlink 3 }
gps OBJECT IDENTIFIER ::= { airlink 4 }

-- GENERAL --
phoneNumber OBJECT-TYPE
SYNTAX DisplayString (SIZE (10))
MAX-ACCESS read-only
STATUS current
::= { general 1 }

deviceID OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
::= { general 2 }

electronicID OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
::= { general 3 }

modemType OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
::= { general 4 }

aleosSWVer OBJECT-TYPE
```



```
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
::= { general 5 }
```

```
aleosHWVer OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
::= { general 6 }
```

```
modemSWVer OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
::= { general 7 }
```

```
modemHWVer OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
::= { general 8 }
```

```
-- COMMON --
date OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
::= { common 1 }
```

```
otaProgrammingEnable OBJECT-TYPE
SYNTAX INTEGER {
disabled(0),
enabled(1) }
MAX-ACCESS read-only
STATUS current
```



::= { common 2 }

devicePort OBJECT-TYPE

SYNTAX INTEGER(0..65535)

MAX-ACCESS read-only

STATUS current

::= { common 3 }

netUID OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-only

STATUS current

::= { common 4 }

netPW OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-only

STATUS current

::= { common 5 }

requestPAP OBJECT-TYPE

SYNTAX INTEGER {

no(0),

yes(1) }

MAX-ACCESS read-only

STATUS current

::= { common 6 }

destinationAddress OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-only

STATUS current

::= { common 7 }

destinationPort OBJECT-TYPE

SYNTAX INTEGER(0..65535)



MAX-ACCESS read-only

STATUS current

::= { common 8 }

serialPortSettings OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-only

STATUS current

::= { common 9 }

serialPortFlowControl OBJECT-TYPE

SYNTAX INTEGER {

none(0),

hardware(2),

software(4) }

MAX-ACCESS read-only

STATUS current

::= { common 10 }

-- STATUS --

ipAddress OBJECT-TYPE

SYNTAX IpAddress

MAX-ACCESS read-only

STATUS current

::= { status 1 }

netState OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-only

STATUS current

::= { status 2 }

netChannel OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-only

STATUS current



::= { status 3 }

rsi OBJECT-TYPE

SYNTAX INTEGER(-125..-50)

MAX-ACCESS read-only

STATUS current

::= { status 4 }

serialSent OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-only

STATUS current

::= { status 5 }

serialReceived OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-only

STATUS current

::= { status 6 }

hostMode OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-only

STATUS current

::= { status 7 }

powerMode OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-only

STATUS current

::= { status 8 }

fixObtained OBJECT-TYPE

SYNTAX INTEGER {

no(0),

yes(1) }



MAX-ACCESS read-only

STATUS current

::= { gps 1 }

satelliteCount OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-only

STATUS current

::= { gps 2 }

latitude OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-only

STATUS current

::= { gps 3 }

longitude OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-only

STATUS current

::= { gps 4 }

END

Warranty Terms and Conditions

The following terms and conditions ("Warranty Terms") govern the warranty services offered to you ("Customer") by AIRLINK COMMUNICATIONS, INC. ("AirLink"), located at 3159 Corporate Place, Hayward, CA 94545, in connection with the sale and licensing of AirLink software and hardware.

Warranty Terms

Standard Software Warranty

AirLink warrants that the AirLink software ("Software") licensed hereunder will perform in substantial conformance to the applicable AirLink software specifications during the warranty period. The warranty period is ninety (90) days from the date of delivery of the Software to Customer. AirLink's sole obligation with respect to this express warranty shall be, at AirLink's option, to refund the license fee paid by Customer for any defective Software or to replace the Software with Software that substantially conforms to AirLink's applicable software specifications.

One Year Standard Equipment Warranty

For a period of one year from delivery, AirLink warrants that the hardware products ("Hardware") will meet AirLink's standard specifications and will be free from defects in materials and workmanship.

Optional Two Year Extended Equipment Warranty

If Customer has purchased this two-year extended warranty option, for a period of three years from delivery, AirLink warrants that the Hardware will meet AirLink's standard specifications and will be free from defects in materials and workmanship.

Optional Four Year Extended Equipment Warranty

If Customer has purchased this four-year extended warranty option, for a period of five years from delivery, AirLink warrants that the Hardware will meet AirLink's standard specifications and will be free from defects in materials and workmanship.



Warranty Conditions

Remedy

If under normal use the Software and/or Hardware (collectively, the "Products") prove to have any such defect and the Customer notifies AirLink of such defect within the warranty period, AirLink, at its option, will either repair or replace the same without charge. The warranty does not apply if the serial number label or any warranty voiding label has been removed or if the Product has been subjected to physical abuse, improper installation, or modification not authorized by AirLink, or if the Product was used in a manner for which it was not intended. Products will be accepted for repair or replacement upon written authorization and in accordance with instructions of AirLink. Customer will obtain a Return Material Authorization ("RMA") number from AirLink's Customer Support, fill out an RMA submission form, and enclose it with the product. Transportation expenses associated with returning such Products to AirLink will be borne by Customer. AirLink will pay the costs of return transportation of the repaired or replaced Products. Please contact AirLink's support group via email at support@airlink.com or telephone at 510-781-9760 to obtain an RMA number. Products deemed by AirLink to be DOA (dead on arrival) may be returned to AirLink for repair, at AirLink's expense, using the standard RMA procedures.

WARRANTY DISCLAIMER

THE WARRANTIES SET FORTH ABOVE ARE IN LIEU OF ALL OTHER WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION WARRANTIES AS TO CONDITION, DESCRIPTION, MERCHANTABILITY, NONINFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. AIRLINK AUTHORIZED DEALER'S OR CUSTOMER'S SOLE AND EXCLUSIVE REMEDY WILL BE AIRLINK'S OBLIGATION TO REPAIR OR REPLACE AS SET FORTH ABOVE. THIS WARRANTY DOES NOT COVER PRODUCTS THAT DO NOT CONFORM TO SPECIFICATIONS BECAUSE OF ACCIDENT, ALTERATIONS, FAILURE TO FOLLOW INSTRUCTIONS, USE OUTSIDE THE SCOPE OF ANY OTHER PROVIDED DOCUMENTATION (E.G., USER GUIDE, INSTALLATION GUIDE, QUICK START GUIDE), MISUSE, ABUSE, NEGLIGENCE, FIRE, FLOOD OR ACTS OF GOD.

LIMITATION OF LIABILITY

AIRLINK WILL IN NO EVENT BE LIABLE TO CUSTOMER OR TO ANY OTHER ENTITY WHICH PURCHASES FROM AIRLINK OR USES ANY PRODUCTS SUPPLIED UNDER THIS AGREEMENT FOR ANY CLAIM FOR INDIRECT, SPECIAL, RELIANCE, INCIDENTAL OR CONSEQUENTIAL LOSSES, DAMAGES OR EXPENSES ARISING OUT OF THIS AGREEMENT OR ANY OBLIGATION RESULTING THEREFROM FOR THE USE OR PERFORMANCE OF THE PRODUCTS, WHETHER IN AN ACTION BASED ON BREACH OF WARRANTY (EXPRESS OR IMPLIED), BREACH OF CONTRACT, DELAY NEGLIGENCE, STRICT TORT LIABILITY OR OTHERWISE. AIRLINK'S ENTIRE LIABILITY FOR ANY CLAIM ARISING FROM ANY CAUSE WHATSOEVER, WHETHER FOR PRODUCTS DELIVERED OR NOT DELIVERED, INCLUDING BUT NOT LIMITED TO THE MANUFACTURE, SALE, DELIVERY, RESALE, REPAIR IN OR OUT OF WARRANTY, USE OR INABILITY TO USE ANY PRODUCTS, EITHER SEPARATELY OR IN COMBINATION WITH ANY OTHER GOODS OR EQUIPMENT, WILL IN NO EVENT EXCEED THE LOWER OF THE REPAIR OR REPLACEMENT COST OR PURCHASE PRICE OF THE PRODUCT WHICH



DIRECTLY GIVES RISE TO THE CLAIM. THIS CLAUSE WILL SURVIVE THE FAILURE OF ANY EXCLUSIVE REMEDY AND THE EXPIRATION OF THESE WARRANTY TERMS.

General Conditions

AirLink shall have the right to assign any or all components of these Warranty Terms without the prior written consent of the other party. AirLink shall not be liable to Customer for any alleged loss or damages resulting from delays in performance (including for AirLink, loss or damages resulting from delivery of the Products being delayed) caused by any act of God, fire, casualty, flood, war, failure of public utilities, injunction or any act, exercise, assertion or requirement of governmental authority, earthquake, labor strike, riot, accident, shortage, delay in transportation or any other cause beyond the reasonable control of AirLink, and if AirLink shall have used its best efforts to avoid such occurrence and minimize its duration and has given prompt written notice to Customer, then AirLink's performance shall be excused and the time for performance shall be extended for the period of delay or inability to perform due to such occurrence. All notices and demands of any kind which either party may be required or desire to serve upon the other under the terms of this Agreement shall be in writing and shall be served by personal service or by registered mail, postage prepaid, to AirLink (Att: VP/Operations) at the address set forth at the beginning of this Agreement, and to Customer, at the address provided by Customer to AirLink on the applicable purchase order. If any provision of these Warranty Terms shall be held to be invalid, illegal or unenforceable, the validity, legality and enforceability of the remaining provisions shall in no way be affected or impaired thereby. The laws of the State of California shall govern these Warranty Terms. These Warranty Terms constitute the entire agreement between the parties hereto pertaining to the subject matter hereof, and any and all written or oral agreements heretofore existing between the parties hereto are expressly canceled and/or superseded. These Warranty Terms shall prevail notwithstanding any variance with terms and conditions of any purchase order. Any modifications of these Warranty Terms must be in writing and signed by a duly authorized officer of both parties hereto.

Frequently Asked Questions and Technical Support

Many of these questions and solutions in the following sections come from AirLink Support.



Caution: Solutions should only be performed if you are experiencing the specific problem indicated and have the specific modem model number indicated. Some solutions are very specific to model numbers due to differing internal hardware.

FAQ Topics

Power, Antennas, and Signal Strength page 95

What is RSSI? Why is the RSSI for my Raven X negative?

What is the Proper RF Coverage for my Raven X?

What Type of Antenna is Best for my Raven X?

What do I need to power my Raven X ?

Can I use a portable battery to power my Raven X ?

The Raven X's IP Addresses and Local Networking. page 97

Why Can't I reach my Raven X from the Internet? What is a Restricted or Private IP?

What is the difference between Private and Public mode?

How do I set up Private Mode? How do I connect to my Raven X to my router or to Linux?

I disabled the DHCP server in my Raven X and now I cannot connect to it, how can I change it back?

Security for the Raven X page 100

Does HSDPA provide any security?

If I change the password in my Raven X and forget it later, can I still access the modem?

Power, Antennas, and Signal Strength



What is RSSI? Why is the RSSI for my Raven X negative?

RSSI (Received Signal Strength Indication) is a measurement of the strength or intensity, not necessarily the quality, of the received signal.

The RSSI is measured in dBm which is the power ratio in decibel (dB) of the measured power referenced to one milliwatt (mW). One milliwatt is zero, therefore less than a milliwatt, common and ideal for cellular communication, is expressed as a negative integer.

***What is the Proper RF Coverage for my Raven X?***

The optimal range for AirLink modems is an RF Coverage (RSSI value) of -60 to -95. RF coverage between -95 to -105 DBm will often still register, however functionality at this range can be greatly reduced and registration can become difficult. Any devices with an RSSI below -105 DBm will likely fail to register on a regular basis.

When addressing RF coverage ensure the antenna choice is appropriate for the device and frequencies required.

***What Type of Antenna is Best for my Raven X?***

Antennas for cellular communication are commonly omni-directional and either dual-band or multi-band. They come in a variety of shapes and mounting configurations to suit several different types of needs.

While AirLink does sell a limited selection of antennas and antenna accessories, these are by no means all that are available or usable with your Raven X. There are several suppliers of cellular accessories with a much wider selection of antennas designed to cater to a broader variety of situations.

Antennas selected should not exceed a maximum gain of 5 dBi under standard installation configuration. In more complex installations (such as those requiring long lengths of cable and/or multiple connections), it's imperative that the installer follow maximum dBi gain guidelines in accordance with the FCC's, regulations.

Dual-band

For cellular communication, the Raven X requires a dual band antenna supporting both 800 MHz and 1900 MHz (1.9 Ghz) bands.

Dipole

Dipole is a common antenna type connecting directly to the Raven X and extending out in a single straight wire.

The short dipole antenna (also known as a "rubber duck") is a good desktop, portable antenna for use in areas with good signal strength and low electrical interference.

Mounts

Antennas can be mounted in a variety of ways (magnet, permanent, suction to a window, sticky tape, etc) which can allow you to move the antenna away from the Raven X with a coax cable between the modem and the antenna allowing the antenna to be placed in a more suitable location for proper cellular reception: outside of a metal cabinet, the trunk lid of a car, a window, etc. A



mounted antenna can be placed in locations where the simple, short dipole antenna connected directly to the Raven X may not perform at all.



Note: When using a cable with an antenna, there is a dB loss over the distance of the cable. It is possible to lose the full gain of an antenna while using a long cable to the modem.



What do I need to power my Raven X ?

Your Raven X is designed to work either with DC (commonly used in vehicles) or with an AC adapter (standard wall outlet in the US, Canada, and most other countries). The input voltage is 9VDC to 28VDC with an input current from 90mA to 350 mA.

If the modem is provided an inadequate power supply the following symptoms might be experienced:

- Modem will constantly power cycle while attempting to register
- Modem will register but will power cycle when data is transmitted/received
- Modem won't power on at all.

If these symptoms occur, verify the power supply meets the above mentioned criteria. If an AC adapter is being used; verify it is intended for the AirLink product in question.



Can I use a portable battery to power my Raven X ?

It is possible to use a portable battery for your AirLink modem, however, you most likely need to make the connector from the battery to the modem yourself. The battery also needs to have enough power to be able to handle the power consumption of the modem.

You can contact AirLink Support for a guide on how to use your AirLink modem with a portable battery.

The Raven X's IP Addresses and Local Networking



Why Can't I reach my Raven X from the Internet? What is a Restricted or Private IP?

On Cingular's network, for security reasons, some accounts set up to be restricted to communication only from other devices on their network, called a Restricted IP or a Private IP. If you had two modems on Cingular's network, they could communicate, but your computer, not using Cingular as an ISP can't. You could normally still access the Internet using your Raven X's restricted or private IP because the modem would use a proxy or gateway on Cingular's network.

However, if you need to be able to contact your Raven X (or the devices behind it) directly, instead of a **Restricted IP** (also called **Private IP Non-Routable IP**), you will need to contact Cingular your cellular provider to get your account changed to an **Unrestricted IP** (also called **Public IP**).



What is the difference between Private and Public mode?

When your Raven X is powered on, ALEOS, acting as a PPP client, negotiates a PPP session with Cingular's network at the conclusion of which it is assigned an IP address by your cellular provider. How this address is further acted upon by the modem is determined by Private or Public Mode.

Public Mode (*HOSTPRIVMODE=0):

The IP address assigned by Cingular is passed on to the devices connected to the modem.

If there is a computer or device connected to the modem's Ethernet port, the IP address assigned by your cellular provider is passed on to the computer or device by the DHCP server in the modem.

Private Mode (*HOSTPRIVMODE=1):

The IP address assigned by Cingular is not the address that is assigned to the computer or device connected to the Raven X's Ethernet port during the PPP negotiation or DHCP IP assignment. Instead, the computer or device connected to the Raven X on the Ethernet port is assigned the IP address configured in *HOSTPRIVIP and uses the IP address configured in *HOSTPEERIP to communicate to the modem.



How do I set up Private Mode? How do I connect to my Raven X to my router or to Linux?

Private Mode is at times preferred or required to provide network connectivity to a Linux device, routers, or other devices. Private mode will generally also work with any PC in an environment where there is a need for the Raven X to be configured to work with an internal network.

There are four AT commands you will need to set in the modem. You can set them using Wireless Ace or a AT commands with a terminal connection (page 34). The examples shown are from Wireless Ace.

***HOSTPRIVMODE=1** - Private Mode turned on.

***HOSTPRIVIP=[IP address]** - IP address assigned to computer or other end device connected directly to the modem (example, 192.168.1.8).

***HOSTPEERIP=[IP address]** - IP address assigned to modem for local, not cellular, communication (example, 192.168.1.9).

***HOSTNETMASK=[subnet mask]** - Subnet Mask setting (example, 255.255.255.0).

The IP addresses configured need to be appropriate for your network. For most internal networks, using the IP range of 192.168.x.x is generally preferred. The first three parts (called octets) need to be the same for all devices on the network (such as 192.168.1.x), but you can use any number from 0 to 254 for the last part if you use a subnet mask of 255.255.255.0 (fewer numbers are usable with different subnets). The last part for each IP address on the network needs to be different.

The *HOSTPRIVIP and the *HOSTPEERIP need to exist on same subnet, the easiest subnet to configure is 255.255.255.0 which allows for 255 IP addresses on the same subnet. Unless you understand the complexities of subnetting or you are instructed to use a different subnet by your Network Administrator, it is safe to use 255.255.255.0 with an internal 192.168.x.x network.



Unless you are instructed to use a different IP range and subnet by your Network Administrator, using the 192.168.1.x or 192.168.0.x range with a subnet mask of 255.255.255.0 is recommended.



Caution: If the IP address of the device or computer connected to the modem is different from the one configured in the modem as the *HOSTPEERIP, communications will fail. If the Subnet Mask is configured differently in the modem than on the computer or device to which it is connected, you may not be able to communicate between them.



I disabled the DHCP server in my Raven X and now I cannot connect to it, how can I change it back?

Since the Raven X has a serial port, you can connect to the modem using Wireless Ace using PPP or use a terminal emulator to connect directly to the serial port. In Wireless Ace (or using terminal emulation), you can change the *DHCPSEVER command to either **1** or **2**.

In Wireless Ace, *DHCPSEVER is part of the PPP/Ethernet group. With a direct serial connection, you would type **AT*DHCPSEVER=1** (to enable it fully) or **AT*DHCPSEVER=2** (to enable the DHCP server only if another DHCP server is not present on the network, this setting is recommended).

Or

If you cannot use serial to connect to the modem, to reset the DHCP server without being able to connect to the modem using Ethernet requires resetting the NVRAM, the internal memory, to the original factory defaults.


Software Required:

Modem Doctor - Utility to conduct diagnostics and to bring your modem to a base-level of configuration. You can download Modem Doctor from the AirLink website: <http://www.airlink.com/support/modems/utilities/>. This utility does not need to be installed; it is run directly. Remember where you downloaded it to, so you can run it as part of the instructions below.

- 1.** Connect the Raven X directly to your computer with a cross-over or standard Ethernet cable, as applicable (Modem Doctor cannot operate remotely).
- 2.** Run Modem Doctor from the location on your computer where you downloaded it.
- 3.** Select **Erase the modem's non-volatile data**.



FIGURE 1. Modem Doctor



4. Select **Ethernet** and enter the **MAC** address listed on a small sticker on the bottom of your Raven X. Enter the **IMEI**, found on the label on the top of the Raven X.

Security for the Raven X



Does HSDPA provide any security?

While the structure of the HSDPA network provides data security, it is still recommended you use a VPN for additional data communication security.

For specific information about the security of Cingular's network, contact your cellular dealer directly.



If I change the password in my Raven X and forget it later, can I still access the modem?


If you changed your password from the default, you can have your password reset by calling or emailing AirLink's technical support.



The support technician will ask you for a **Challenge Code** which you can obtain using Wireless Ace. You will be asked to send this information in an email to support@airlink.com along with your name and company. Password resets are tracked.


1. Start Wireless ACE: *Start > All Programs > AirLink Communications > Wirelss ACE 3G > Wireless ACE 3G*
2. Select *Modem > Reset Password*.

FIGURE 2. Wireless Ace: Reset Password



3. Note the Challenge Code shown (will be different than this screenshot).

FIGURE 3. Wireless Ace: Challenge Code



4. Enter the **Daily Password** provided by the AirLink support technician.



Note: The Daily Password will only work for the modem you requested, the copy of Wireless Ace you used to obtain the Challenge Code, and only for the specific time (approximately 24 hours).



AirLink Technical Support

If you encounter problems with operation of your Raven X, AirLink's support staff can help.

AirLink Support Web Site

The AirLink web site is updated frequently with Setup Wizards, Utilities, How-To Guides, and other documentation: <http://www.airlink.com/support>.

AirLink Documentation and Guides

- **Modem User Guides** - These guides are specific to your modem type, cellular provider, and cellular technology and contain comprehensive information about the operation of the modem and its features.
- **Modem Quick Start guides** - These guides are also specific to the modem type, cellular provider, and cellular technology and are a step by step guide to activating the modem using the Setup Wizard or other steps as applicable.
- **Utility Guides** - These guides focus on the features of one of the AirLink modem utilities: Wireless Ace, AceView, AceNet, Modem Doctor, etc.
- **Application Notes and How-To Guides** - These guides detail configuring the modem to work with a specific feature set or how the modem can be set up to work with a specific 3rd party (non-AirLink) device.
- **Data Sheets and White Papers** - These are technology based information documents.

Contacting Technical Support

For support assistance please email support@airlink.com or call **510-781-9760** Monday through Friday 5 AM to 5 PM Pacific Time (8 AM to 8 PM Eastern Time). Support is not available weekends or holidays.